

<b>Item #:</b>	WHAP2057
<b>Product Name:</b>	5.5Ft Pre-Lit Green Artificial Tree with Top Hat Pot

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

### PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from Styrofoam and bubble wrap inside the carton to ensure there are no missing or damaged parts. Do not attempt to assemble or use the product if any parts are missing or damaged.

### CARTON CONTENTS:

Description	Quantity
Tree Top (A)	1
Tree Middle (B)	1
Tree Bottom (C)	1
Tree Pot	1
UL 120V Transformer	1

### Before You Start


- Decide on an appropriate location for your product, please read assembly and Instruction procedure carefully.  
Note: This tree may utilize light sets that are marked for indoor and outdoor use, but the artificial tree is for indoor display only.
- Retain the instructions for future use and save the carton for storing your tree.

### Assembly and Instruction Procedure (No tools required for assembly):

Remove all packaging (i.e., cardboard or plastic) before beginning. We suggest unpacking the tree on a large cloth. If your tree is snow-flocked, then some of the flocking may come off during unpacking and fluffing branches.

- Assemble the Tree:  
Place the pot base on a flat surface. Carefully insert the bottom of the tree section (C) into the pot, making sure the tree pole is firmly inserted.  
Insert the middle section (B) into the bottom section (C). And lastly, insert the tree top (A) into the middle section (B). Take care not to place unnecessary pressure on the brackets during assembly.  
Now that the tree is fully assembled connect the light plugs as shown in the image below. Attach the plug to the string lights located in the bottom section of the tree and plug into an electrical outlet. If lights do not come on, skip to the section for troubleshooting tips.

<b>Item #:</b>	WHAP2057
<b>Product Name:</b>	5.5Ft Pre-Lit Green Artificial Tree with Top Hat Pot



### 2. Shape the Tree:

The branches on your tree can be adjusted to give your tree the desired fullness. Begin to shape the branches from the bottom of the tree to the top. Start with the tree tips farthest away from the center pole.

Straighten and separate all branch tips for the best results, then bend them slightly upward.

After shaping the tree, step back to look for any gaps. Reshape branches as needed. You can upsweep the branch tips for a uniform look. Once you have the tree the way you want it, you can start decorating!




Fig.1




Fig.2




Fig.3

### 3. Plug tree lights into a power outlet. If lights do not come on, skip to the Troubleshooting section.

### 4. At the top of the Plug there is a black button that operates the lights with 10 functions as follows:

1	Combination	6	C1 & C2 Sequential
2	C1 Steady ON	7	C1 & C2 Twinkle/Flash
3	C2 Steady ON	8	C1 & C2 Slow Fade
4	C1 Slo Glo	9	C1 & C2 Slo-Glo
5	C2 Slo Glo	10	Off

**YOUR TREE IS NOW READY TO ENJOY!**

<b>Item #:</b>	WHAP2057
<b>Product Name:</b>	5.5Ft Pre-Lit Green Artificial Tree with Top Hat Pot



### Warnings:

1. Risk of Fire and Electric Shock – please follow instructions and warnings on string lights if adding lights to the tree.
2. Do not place it near fireplaces, candles, outdoor heaters, or other similar sources of heat. This item is not flame retardant.
3. Do not install near pools, fountains, tubs, sinks, or other areas of standing water that the tree may fall or blow into.
4. Keep wires clear of being pinched or cut during assembly or installation. Discard sets with cut or pinched insulation.
5. Make sure the final assembly stable enough to hold the tree upright.
6. Do not use candles on the tree. Use only with the pre-installed string lights included.
7. This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.

### Troubleshooting:

1. Some bulbs are not lighting, or lights do not come on at all: Search for any loose plug connections between the tree sections. Search for loose or missing bulbs.
2. Tree is not straight: Try adjusting the pole to ensure it is securely fitted into the pot. It is better if the tree is in the vertical position when adjusting.

Note: If these actions do not resolve the issue with the tree, please do not disassemble the tree yet. Please contact customer service for assistance.

### Storage:

1. Remove all decorations (this does NOT include the pre-installed string lights).
2. Remove the tree from the pot. Press the tree tips back up against the pole.
3. Place the tree back into the carton.
4. Store the product in a cool, dry location protected from sunlight where the temperature does not exceed 35°C (95°F).