
MODEL NUMBER: BF-744B (PC+DD)



WARRANTY:

We stand behind our products & service with confidence!If parts damaged or missing please feel free to contact us for a FREE REPLACEMENT.

We warranty this product to be free from defects in materials. This warranty covers one year from the date of original purchase.

NOTES:

- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.

WARNING:

• WARNING FOR YOUNG CHILDREN - This product contains small components, please ensure that they are kept away from smallchildren while assembling.

1


PARTS LIST

A B	С	D	E)	F	F		Н		Ι	
1PC 1PC	IPC	IPC	2P(CS CS	2PCS		1PC	1PC		2PCS	
J			K				L	N		N	0
op.cs			1PC			1				100	10000
2PCS P			Q	R		1PC S		1P a	b	1PC d	10PCS e
2PCS			2PCS	1PC			1PC	1/4*95 4PCS	1/4*60 14PCS	1/4*35 10PCS	1/4*19 17PCS
m	g		h	i	X		Z	j	1		
M6*23 12PCS	4PCS)	8PCS	© 6PCS	1/ 2P	/4 CS	1PC	M4*12 2PCS	1PC		


IMPORTANT:

Please check parts list before you start to assembly. If parts damaged or missing. Contact your seller for a FREE REPLACEMENT. Please provide your order number, a brief message about the issue, and your shipping address. Thank you!


NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED




If you have any questions, pls contact us via "Contact Seller" in your order profile.



NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED



NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED



IMPORTANT: Please completely tighten all the bolts and nuts.

If you have any questions, pls contact us via "Contact Seller" in your order profile.