


ASSEMBLY INSTRUCTION


SKU CODE: (WF324173/WF324174)




ASSEMBLY INSTRUCTION












Assembly Tools Required (Not Included)


Part List (WF324174)




STEP 1: Following below illustration:














STEP 4: Following below illustration:

















FINISH

