


Thank You For Shopping With COZAYH HOME

We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.

Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: Support@cozayh.com













Website: www.cozayhhome.com




SKU:
F02050

Assembly Instructions

Laying out all parts and hardware and identifying each part as shown may help you assemble the end table.

ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY
A		Top Panel	1	C		Shelf Panel	1	E		Drawer Assembly	1
B		Cabinet Assembly	1	D		Back Panel	1	F		Drawer Bottom Panel	1
G		Screws (6*25mm)	4	I		Leg leveler	4	K		Allen wrench	1
H		Flat washer	4	J		Shelf Stopper	4	L		Dower Pin	2

STEP 1



Unfold the cabinet assembly and attach the levelling feet.


WARNING

- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard – Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 50 Lbs. Do NOT overload.




COZAYH HOME

STEP 2




Insert the dowel pins and unfold the bottom panel.

STEP 3




Tuck the back panel in the wood slots.

STEP 4




Place the top panel and secure with screws and washers as shown.


STEP 5



Unfold the drawer assembly and place the bottom panel.




STEP 6



Plug in the shelf stoppers.

STEP 7



Insert and sit the shelf panel on the stoppers.