

TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - Persons Recommended

ASSEMBLY RATING



EASY-DIFFICULT

The Assembly Rating is a 5—point system showing the level of effort needed to assemble a specific product.

VERSION # 24-04-25



	Are you missing anything? Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
_	Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling. Set up your workspace by laying the parts and hardware out separately, then begin!

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

EASTERN KING BED




- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

Parts List (Box 1) Headboard Box








Headboard


Footboard

Headboard Leg L&R

Parts List (Box 2) Side Rail Box









Side Rail

T-Runner Center Support

Bed Slat w/o marking 1951 x 45 x 18mm


Bed Slat with marking 1951 x 45 x 18mm











FB T-Runner Slat


1pc

365 x 30 x 30mm

Support 145 x 30 x 30mm

Concealed Panel 2040 x 295 x 9mm

Parts List (Box 3) Drawer Box



Footboard Drawer

HARDWARE

Hardware List (Box 1) Headboard Box



6pcs



6pcs



6pcs



1pc





Bolt 1/4" x 1-3/16" Lock Washer

Flat Washer

Allen Key M4

Hardware List (Box 2) Side Rail Box



11pcs



8pcs



12pcs



2pcs









Bolt 1/4" x 2"

Flat Washer (IF NECESSERY USE ONLY) CSK m4 x 32mm

CSK m4 x 20mm













P.H Screw m3.5x20mm


Allen Key M4

Allen Key M5

packed in 3 cartons

Carton	Designation		Part	Hardware	
	King Size Bed HB, FB & HB Legs			X 1	A x 6pcs B x 6pcs
	2		X 1	© C x 6pcs	
		3		X 2	
	King Size	4			① E x 11pcs
	Bed Rails	_		X 2	F x 8pcs
		5		X 1	⊕
		6		Х3	()
		7		X 2	J x 1pc K x 1pc
		8		X 10	
		9		X 1	
		10			
				X 6	
	King Size Drawer	11			
			V	X 2	


Prepare 6 bolts assembly by inserting lock washer (B), then flat washer (C) onto bolts (A). Align HB legs (3R/L) to the holes of the headboard (1). Secure by usingbolts (A).




2


Part② x 1pc
Part④ x 2pcs


- 1) Loosen the bolts attached to headboard (1) and footboard (2), then hook the side rails (4) to the loosed bolts on the headboard (1) and footboard (2).
- 2) Tighten the bolts on the headboard (1) and footboard (2) to the side rail hooks (4).




Align T-Runner Center Support (5) to the side rails (4), then secure by using screws (G). Part x 1pc Hardware (G) x 2pcs 4 G Part 9 x 1pc Align Footboard T-Runner Slat Support (9) to the hole of the Hardware x 1pc T-Runner Center Support (5), secure with JCBC (E) tighten with Allen Key (J), then adjust leveler of the Footboard T-Runner Slat Support (9) according to ground level. **x1** 5











10



11



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.