# **Assembly Instructions**

Caution: You must read this before you proceed

## Care & Maintenance



Not for commercial use. For residential use only.



• Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only.



 Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.




 Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in chair for hardware packs and legs.

Sets often ship in multiple boxes and may arrive a day or two apart.

# **Club Chair**




Parts List				
Label	Picture	Description	QTY	
Α		Backrest	1	
В		Seat Surface	1	
С	• • • • • • • • • • • • • • • • • • •	Left Leg	1	
D		Right Leg	1	
E		Pillow	1	

Hardware				
Label	Picture	Description	QTY	
1		Bolt M8X40mm	9	
2		Spring Washer	9	
3		Flat Washer	9	
4		Allen Wrench	1	

# **Assembly Preparation**







· Read instructions, cover to cover-



• Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




• Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

# Overview Backrest(A) Pillow(E) Right Leg(D) Seat Surface(B) Left Leg(C) FRONT FACING


This chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Take out the backrest(A) and seat surface (B) first, align the holes on the seat(B) with the holes on the backrest(A). Unzip the non-woven zipper at the bottom of the seat to expose the entire bottom, make sure the holes on the seat and backrest are aligned, then tighten the screw with the Allen Wrench(4) socket.



Straighten the assembled backrest and seat, take out the Left leg(C) and right leg(D), and insert the leg into the plug-ins at the left and right ends of the backrest(A).



## Step2.1


Lay down the installed legs as shown to expose the bottom. There are two rows of holes on the left and right ends of the seat surface(B). Please align the left and right holes with the reserved holes of the left and right legs and use the Allen Wrench(4) locking screws.

## Step2.2


Zip up the zipper at the bottom of the seat after the seat and legs are locked and fixed

## Step2.3

The bottom of the product after it has been zipped up.



Put the Pillow(E)on the backrest as shown.



Place the CHAIR right side up and tested for stability before it is ready for use. This CHAIR can only be used on a flat, level surface.