
## **Assembly Instructions**

Caution: You must read this before you proceed

#### Club Chair



# Parts List


| Label | Picture | Description       | QTY |
|-------|---------|-------------------|-----|
| A     |         | Chair Backrest    | 1   |
| В     |         | Chair Seat        | 1   |
| С     |         | Front Wooden Legs | 2   |
| D     |         | Back Wooden Legs  | 2   |

### Hardware

| Label | Picture | Description          | QTY |
|-------|---------|----------------------|-----|
| 1)    |         | Bolts                | 6   |
| 2     |         | Allen Key            | 1   |
| 3     |         | Flat Washer Rings    | 6   |
| 4     | Q       | Spring Washer Rings  | 6   |
| 5     |         | Plastic Washer Rings | 7   |

## **Assembly Preparation**

Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-

#### Assembly Steps


#### Step 1




Position Chair Seat on its back, as shown.

DO NOT place on surface that can scratch or damage upholstery. Unzip to open and remove the 4 wooden legs.

Close pouch before assembling.



Put the Chair backrest(A) onto a flat table or panel, Insert the Chair seat(B) into Chair Backrest (A) as denoted above.



Put the Chair Backrest(A) down as shown in above picture. Attach Chair Seat(B) to Chair Backrest(A) using Bolt(①), Spring Washer Rings(④), and Flat Washer Rings(③) with Allen Key(②) as pictured above. Tighten the Bolt fully.


# Step 4 Use Plastic Washer Rings(⑤) to achieve stability

Install the Legs(C) and Legs(D) at the base of the Chair Seat(B).

Insert threaded stems of Legs into the mounting position at the corners of the Chair Seat(B).

Tighten by turning the Leg clockwise by hand.

Note: The use of Plastic Washer Rings(⑤) are OPTIONAL and are especially useful to help alleviate slight wobbles. Some Legs may need more than one gasket whilst some Legs may not need any.



Make sure all parts are connected and securely locked into position. Your chair is ready for use.

#### Care & Maintenance



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



• Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only.



Not for commercial use. For residential use only.



 Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth.