


TOOLS REQUIRED





Phillips Screwdriver

(Not Included)




2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT


The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



	Are you missing anything?		Check out our Quick Tips!
	Double-check all parts, hardware and accessories listed are all acccounted for.		We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
П	Should we send any replacements?		Prep Time!
	Are there any irregularities or flaws in the parts? We can send replacements!		Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

QUEEN BED



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS



















HEADBOARD 1pc



HEADBOARD LEGS L/R 2pcs



STRETCHER 1pc
















SIDE RAILS 2pcs




SLATS 5pcs



SUPPORT SLATS 5pcs

HARDWARE


1.ASSEMBLY HEADBOARD




2.ASSEMBLY FOOTBOARD

E	F	G	H
ALLEN WRENCH 1pc	BOLT 5/16" 1 " 4pcs	LOCKWASHER 5/16" 4pcs	FLAT WASHER 5/16" x 19mm 4pcs


3 .ASSEMBLY SIDE RAILS







EXPLODED VIEW




packed in 3 cases

Carton	Disignation		Part	Hardware
	Headboard	#1		# A x 1pc
	Headboard legs L/R	# 2		# C x 8pcs # D x 8pcs
	Stretcher	#3		
	Footboard	# 4		#E x 1pc
	Metal legs	# 5		# G x 4pcs # H x 4pcs
	Side rails	# 6		# I x 1pc # J x 8pcs
	Slats	#7		# K x 8pcs # L x 8pcs
	Support Slats	#8		ໜ່ານານ # M x 10pcs


1 . Part #1 x 1pc
Part 2# x 2pcs
Hardware # A x 1pc
Hardware # B x 6pcs
Hardware # C x 6pcs
Hardware # D x 6pcs

Attach the Headboard Legs (#2) to the Headboard (#1). Secure by using Bolt (#B) with Lock Washer (#C) and Flat washer (#D) Allen wrench(#A).



2 . Part #1 x 1pc
Part 2# x 2pcs
Part 3# x 1 pcs
Hardware # A x 1pc
Hardware # B x 2pcs
Hardware # C x 2pcs
Hardware # D x 2pcs


Attach the Stretcher (#3) to the Legs (#2). Secure by using Bolt (#B) with Lock Washer (#C) and Flat washer (#D) Allen wrench(#A).




3. Part # 4 x 1pc
Part # 5 x 2pcs
Hardware # E x 1pc
Hardware # F x 4pcs
Hardware # G x 4pcs
Hardware # H x 4pcs

Attach the Metal Legs (#5) to the Footboard (#4). Secure by using Bolt (#F) with Lock Washer (#G) and Flat washer (#H). Allen wrench(#E).

4 .Headboard x 1pc
Footboard x 1pc
Part # 6 x 2pcs
Hardware # I x 1pc
Hardware # J x 8pcs
Hardware # K x 8pcs
Hardware # L x 8pcs







Screw the Bolt (L) into HB & FB.

Align the bolts with the holes in the end of side rails and attach the side rails to HB & FB using half moon washers (F) and nuts (G). Then use a hex wrench (I) to tighten all the nuts.

4 .Headboard x 1pc
Footboard x 1pc
Part # 6 x 2pcs
Part # 7 x 5pcs
Part # 8 x 5pcs
Hardware # M x 10pcs

Attach Support Slat (#8) to the Slat (#7) Rotating tightly and attach Slats(#7) to the Side rails (6) using wood screws (#M).





ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reterence.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.