



ASSEMBLY INSTRUCTIONS



TOOL REQUIRED



Allen Wrench
(Included)



Phillips
Screwdriver
(Not Included)



2 - People
Recommended

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



NO. 9,200,656
Insert & Lock Joint
Structure



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


















TWIN FULL BUNK













- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.























PARTS








A		B		C		D	
	UPPER HEADBOARD/ FOOTBOARD 2pcs		LOWER HEADBOARD 1pc		LOWER FOOTBOARD 1pc		LOWER FRONT SIDE RAIL 1pc
E		F		G		H	
	LOWER REAR SIDE RAIL 1pc		UPPER FRONT SIDE RAIL 1pc		UPPER REAR SIDE RAIL 1pc		GUARD RAIL SUPPORT 3pcs
I		J		K		L	
	FRONT GUARD RAIL 2pcs		REAR GUARD RAIL 2pcs		CENTER RAIL 1pc		LADDER (LEFT) 1pc
M		N		O		P	
	LADDER (RIGHT) 1pc		LADDER STRETCHER 4pcs		TRIANGLE PANEL 1pc		UPPER SLAT 1set
Q							
	LOWER SLAT 1set						

HARDWARE

- | | | | |
|--|---|---|---|
| 1

JCBC M6 x 70mm
32pcs | 2

JCBC M6 x 30mm
10pcs | 3

JCBC M6 x 16mm
6pcs | 4

JCN NUT
6pcs |
| 5

JCBC-W M6 x 28mm
16pcs | 6

WOOD SCREW
M4 x 28mm
50pcs | 7

WOOD DOWEL
Ø10 x 30mm
16pcs | 8

BARREL NUT
M6 x 13mm
32pcs |
| 9

METAL HOLLOW PIN
4pcs | 10

ALLEN KEY M4
1pc | | |


packed in 3 cartons

Carton	Designation		Part	Hardware
	Upper Headboard/ Footboard	A	 X 2	 #1 X 32  #2 X 10  #3 X 6  #4 X 6  #5 X 16  #6 X 50  #7 X 16  #8 X 32  #9 X 4  #10 X 1
	Upper Slat	P	 X 1	
	Lower Headboard	B	 X 1	
	Lower Footboard	C	 X 1	
	Upper Slat	Q	 X 1	
	Lower Front Side Rail	D	 X 1	
	Lower Rear Side Rail	E	 X 1	
	Upper Front Side Rail	F	 X 1	
	Upper Rear Side Rail	G	 X 1	
	Guard Rail Support	H	 X 3	


Carton	Designation		Part	Hardware
	Front Guard Rail	I	 X 2	
	Rear Guard Rail	J	 X 2	
	Center Rail	K	 X 1	
	Ladder (Left)	L	 X 1	
	Ladder (Right)	M	 X 1	
	Ladder Stretcher	N	 X 4	
	Triangle Panel	O	 X 1	

ASSEMBLY INSTRUCTION

STEP 1




OPTION 1





OPTION 2

STEP 2




ASSEMBLY INSTRUCTION

STEP 3




STEP 4




ASSEMBLY INSTRUCTION

STEP 5





STEP 6





ASSEMBLY INSTRUCTION

STEP 7




STEP 8





ASSEMBLY INSTRUCTION

STEP 9




STEP 10




ASSEMBLY INSTRUCTION

STEP 11




STEP 12




ASSEMBLY INSTRUCTION

STEP 13




STEP 14




ASSEMBLY INSTRUCTION

STEP 15




STEP 16



ASSEMBLY INSTRUCTION

COMPLETE



ASSEMBLY COMPLETED



Please ensure the furniture rest on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screw are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.




Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

Safety Warnings for Bunk Beds

1. Read and follow the information on the WARNING labels shown on the end structure of the upper bunk and on the carton.
2. Do not remove warning labels from the bed.
3. Keep these instructions for future use.
4. **IMPORTANT:** The proper sizes for the UPPER TWIN-SIZE mattress should be 74"-75" long and 37 ½"-38 ½" wide with no more than 6" thickness and for the LOWER FULL-SIZE should be 74"-75" long and 53"-54" wide with no more than 6" thickness.
5. Surface of mattress must be at least 5 inches (127 mm) BELOW the upper edge of the guardrails.
6. The **MAXIMUM** weight capacity for the upper bunk is not to exceed 150 lbs.
7. Do not allow children under 6 years of age to use the upper bunk.
8. Periodically check and ensure that the guardrails, ladder, handle and other components are in their proper position, free from damage, and that all connectors are tightened and secured.
9. **DO NOT** allow horseplay, rough playing, or jumping on the beds and do not allow playing or hiding under the beds.
10. Always use the ladder for entering or leaving the upper bunk.
11. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
12. Use of a nightlight may provide added safety precaution for a person using the upper bunk.
13. Always use the guardrails on both sides of the upper bunk.
14. If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and the wall.
15. The use of water or sleep flotation mattresses is prohibited.
16. No more than one person is allowed on the upper bunk at all times.
17. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.



Objects such as, but not limited to, hanger, hooks, belts, bag, rope strings, etc. should not be hanged or used on or around the bunk bed.