
# ASSEMBLY INSTRUCTIONS



### **TOOLS REQUIRED**



Screwdriver (Not included)




Allen Wrench




2 - People

## **ASSEMBLY RATING**



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



	Are you missing anything?	Che	ck out our Quick Tips!
	Double-check all parts, hardware and accessories listed are all acccounted for.		ecommend reviewing the pre-assembly louts. Even experts need a refresher now and
	Should we send any replacements?	Pre	p Time!
	Are there any irregularities or flaws in the parts? We can send replacements!		se review the assembly instructions and all rams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



#### **Teamwork**

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

#### Suitable Location

Assembling near the area of the intended location is highly recommended.

#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.

#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.

### Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# **ASSEMBLY** AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY, THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


# **MIRROR**



- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.





### **PARTS**



### **HARDWARE**

## HARDWARE INSIDE MIRROR





Panhead Screw M4x30mm

# assembly within 2 items

CARTON	DESCRIPTION	PART	HARDWARE
	MIRROR	① / x1	A x 8 PCS
	MIRROR SUPPORT	2 === x2	
	DRESSER	3 x1	Bx8PCS Cx8PCS
	LEG	4 💮 x4	D x 8 PCS  E x 1 PC
	VERTICAL LEG	⑤ <b>←</b> x1	- EXTPC

### **ASSEMBLY INSTRUCTIONS**

Part 1 1pc Part 2 2pcs Hardware A 4pcs

Align an attach the mirror support (#2) to the mirror (#1) by using the Screw (#A).


Follow the line that has been provided for

alignment.

Part (3) 1pc Hardware A 4pcs

Attach the bottom holes of the mirror support (#2) to the dresser (#3) by using Screw (#A).

Match arrow at back side for Mirror (#1) and Dresser (#3).



### **ASSEMBLY** COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.