# **Assembly Instructions**

Caution: You must read this before you proceed

### Care & Maintenance



• Not for commercial use. For residential use only.



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



• Do not put hot items directly on furniture surface.



• Do not clean furniture with harsh cleansers or polish.



• Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



• Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only.



 Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.




 Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in the magic tape pouch for hardware packs and legs.

Sets often ship in multiple boxes and may arrive a day or two apart.

# Recliner




Parts List				
Label	Picture	Description	QTY	
A		Chair Backrest	1	
В		Left Wing	1	
С		Right Wing	1	
D		Chair Base	1	
Е		Front Leg	2	
F		Hind Leg	2	

<u>Hardware</u>					
Label	Picture	Description	QTY		
1	0	Bolt(M8*25mm)	3		
2	0	Flat Washer	3		
3	٥	Spring Washer	3		
4		Allen Wrench(S5)	1		
(5)	<b>%</b>	Plastic Washer	7		
6	$\odot$	Rubber Gasket	3		

## **Assembly Preparation**

Before Beginning Assembly:





· Read instructions, cover to cover-



• Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-


## **Assembly Steps**



This Recliner Chair has multiple parts and may require about 30 minutes to assemble. To give you an overview of the Recliner Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise the parts and steps before assembly.




Place the Chair Base(D) on a clean, non-marring surface. Remove the inner box containing four wooden legs and Hardware pack, as picture shown on above.



Position the Chair Base(D) on its back, on a clean, non-marring surface. Extend the Footrest to open.

Carefully remove the inner box containing Left Wing(B) & Right Wing(C) as shown above.

Stow the Footrest to original position.




Position the Chair Base(D) on its back, as shown above.

Install the Front Leg(E) to Chair Base(D) with Plastic Washer(⑤) by turning the legs clockwise as shown.

Repeat the same steps to install the remaining Front Leg(E).


Note: The use of Plastic Washer(⑤) are OPTIONAL and are especially useful to help alleviate slight wobbliness. Some Legs may need more than one Plastic Washer(⑤) whilst some Legs may not need any.

### Step 4




Install the Hind Leg(F) to Chair Base(D) using Plastic Washer(⑤) ,Rubber Gasket(©), tighten by turning the Hind Leg(F) clockwise.

### Step 5




Attach the Hind Leg(F) to the Chair Base(D) using Bolt(①) ,Spring Washer(③),Flat Washer(②) with Allen Wrench(S5)(④) turning clockwise until tight.

#### Step 6



With assistance from your adult partner, hold up the Chair Backrest(A) stand behind the chair. Insert the small metal arms on the sides of the Chair Backrest(A) into the prefabricated slide lock gadget on the Chair Base(D) as shown above. Firmly but gently, push the Chair Backrest(A) downwards until the Chair Backrest(A) is fully slotted and locked into position.


### Step 7



Smooth down the fabric flap on the Chair Backrest(A).

Run your hands down both sides of the flap, from top to bottom, allowing the magic tape to adhere to the flap under the seat of the chair.

#### Step 8




Position the Chair Backrest(A) on the flat surface.

Slide the Tapered Connectors on the Right Wing (C) into the Tapered Connectors on the Chair Backrest(A).


Then slide Right Wing (C) forward by hand to make sure it locks into the position as shown in the picture.

Repeat the same steps to install the Left Wing(B).

#### Step 9



Sitting on the chair and lying down, chair can become as shown in the picture.



Your Recliner is ready for use.

This Recliner can only be used on a flat, level surface.


#### **User Instructions.**

#### **Recliner Chair**

Please read the Instruction Manual below carefully before use.

This is a Recliner Chair. At anytime in a reclined seat position or in the upright position. You may enjoy the rocking motion by using your body weight in a back-front rocking motion.

Supervise children, when in use of this Recliner.



Always leave the chair in an upright and closed position after use.

Keep hands and feet clear of the footrest mechanism and any gaps.

Do not allow children to play on the chair.

Do not lean to side to pick up anything while sitting on the chair.

Do not sit on the arms.

Do not stand up when the recliner open.

Only the occupant should operate the chair.

#### To get into a reclined posture - To Recline backrest

Sit into the seat.

Place your feet apart.

Place your left and right arm onto the armrest.

Synchronise a backward push with your arms.

Use your body weight and push backwards into the seat into a fully reclined position.



#### To get out of chair - move Seatback into Upright Position

Tilt your body weight slightly forward and upwards.

The seat back will come up to an upright position.

Where necessary, use either your arms help lift- push yourself out of the seat.







