# **ASSEMBLY INSTRUCTIONS**

### **TOOLS REQUIRED**



Screwdriver (Not included)



Allen Wrench



3 - People Recommonded

### **ASSEMBLY RATING**









EASY - DIFFICULT

The Assembly Rating is a 5-point system showing the lavel of effort needed to assemble a specific product



Are you missing anything?  Double-check all parts, hardware and accessories listed are all acccounted for.	Check out our Quick Tips!  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?  Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





#### **Teamwork**

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.





#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.





#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

# **PRODUCT TYPE**



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.
















Dresser

Mirror

Support Rail









**Tipping Restraint** 



Allen Key 4mm



Bolt Ø1/4"x1-1/2"

(#D) 8pcs.






Lock Washer Ø1/4"

Flat Washer Ø1/4"\*19mm

Carton	Designation	Part		Hardware	
	Dresser	#1			#A x 1pc
		#2			#B x 1pc
Mirror	Mirror				#C x 8pcs
	Support Rail	#3		<b>©</b>	#D x 8pcs
				0	#E x 8pcs



### **ASSEMBLY INSTRUCCTION**

1

Part (#1) x 1pc

Part (#2) x 1pc

Part (#3) x 2pcs


Hardware (#A) x 1pc


Hardware (#B) x 1pc

Hardware #C x 8pcs

Hardware #D x 8pcs

Hardware #E x 8pcs





Furniture Tipping Restraint must always be used to prevent the Furniture from tipping.

# ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

### ✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.