


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Allen Wrench

(Included)



Phillips
Screwdriver

(Not Included)



2 - People
Recommended

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DRESSER MIRROR




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

#1 1pc




DRESSER

#2 1pc




FRONT BUN FOOT (L)

#3 1pc




FRONT BUN FOOT (R)

#4 1pc




BACK BUN FOOT (L)

#5 1pc



BACK BUN FOOT (R)

#6 1pc




SUPPORT LEG
98*30*30MM

DRESSER MIRROR




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#7 1pc



MIRROR

#8 2pcs



MIRROR SUPPORT

HARDWARE

#A 8pcs




FLAT WASHER
(5/16")*19MM

#B 8pcs



SPRING WASHER (5/16")

#C 8pcs



HEX NUT (5/16*12MM")

#D 1pc




WRENCH (5/16"*12MM)

#E 1pc



TIPPING RESTRAINT X 1

#F 8pcs



BOLT (1/4" * 1 3/4")

#G 8pcs



SPRING WASHER (1/4")

#H 8pcs







FLAT WASHER (1/4")*19MM

#I 1pc



ALLEN KEY M4



Carton	Disignation	Part		Hardware	
	DRESSER	#1			
	FRONT BUN FOOT (L)	#2			#A x 8pcs
	FRONT BUN FOOT (R)	#3			#B x 8pcs
	BACK BUN FOOT (L)	#4			#C x 8pcs
	BACK BUN FOOT (R)	#5			#D x 1pc
	SUPPORT LEG	#6			#E x 1pc
	MIRROR	#7			#F x 8pcs
	MIRROR SUPPORT	#8			#G x 8pcs
					#H x 8pcs
					#I x 1pc

ASSEMBLY INSTRUCTIONS

1


Part **#1** 1pc

Part **#2** **#3** **#4** **#5** **#6** 1pc

Hardware **#A** **#B** **#C** 8pcs

Hardware **#D** 1pc

Attach foot (**#2**, **#3**, **#4**, **#5**, **#6**) to Chest (**#1**).



2


Part **#7** 1pc

Part **#8** 2pcs

Hardware **#F** **#G** **#H** 8pcs

Hardware **#I** 1pc

Attach support mirror (**#8**) to Mirror and Dresser (**#1**).





ASSEMBLY INSTRUCTIONS

3

Hardware **#E** 1pc

Attach Tipping Restraint (#E) to Dresser (#1).



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.