
ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY ──DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?		Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.		We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the		Prep Time!
•	Ш	Please review the assembly instructions and all

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

E.KING BED



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.







SIDE RAILS

HARDWARE





BOLT (5/16" *1 3/4")





BOLT (1/4" *1 5/8")





ALLEN KEY M4





THREAD BOLT (5/16 *3 5/8")





WRENCH (5/16"*12MM)

(#B)6pcs



SPRING WASHER (5/16")





SPRING WASHER (1/4")





SCREW (Ø4*30MM)





CURVED SLOTTED WASHER





FLAT WASHER (5/16")*19MM





FLAT WASHER (1/4")*19MM






WOOD DOWEL (8*30MM)






DOUBLE HEX NUT




packed in 3 cases

Carton	Disignation	Part	Hardware
	HEADBOARD	#1	#A x 6pcs #B x 6pcs #C x 6pcs
	LEGS	#2	#D x 2pcs #E x 2pcs
	STRETCHER	#3	#F x 2pcs #G x 1pc #I x 4pcs
	FOOTBOARD	#4	
	SLAT	#5	#G x 10pcs
	SUPPORT LEG	#6	
	SIDE RAILS	#7	#J x 8pcs #K x 8pcs #L x 8pcs
			#M x 1pc

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS



This product is intended for RESIDENTIAL USE ONLY and not for commercial use.