


ASSEMBLY INSTRUCTIONS

CABINET

SKU: N711P186790






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

1. Note: This is not a clothing storage cabinet and it is not recommended to use it as a clothing storage cabinet.
2. All cabinets come with TRD, stainless steel or our "L-Bracket "when shipped.







Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions












	<p>Diagram A</p> <p>Insert Cam Bolt into hole as shown in diagram A.</p>
	<p>Diagram B</p> <p>Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.</p>
	<p>Diagram C</p> <p>Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.</p>
	<p>Connect the panels together.</p>
	<p>Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.</p>
	<p>To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i></p>

Detail View - CABINET

















Identifying the Hardware - Identify the hardware using the illustrations below.


Part List

1		2	
	Side Panel (L) - 1pc		Side Panel (R) - 1pc
3		4	
	Mid Panel - 1pc		Bottom Panel - 1pc
5		6	
	Top Panel - 1pc		Back Panel - 2pcs
7		8	
	Adjustable Shelf - 2pcs		Door Cabinet (L+R) - 2pcs
9		10	
	Door Cabinet (M) - 2pcs		Cabinet Feet - 4pcs
11			
	Cabinet Feet (M) - 1pc		


Hardware List

A  ø6x35mm	B  ø14.5x12mm	C  ø8x30mm
Three in one bolts - 4pcs	Three in one lock - 4pcs	Wood dowel - 12pcs
D  ø13x1/4"x28mm	E  ø1/4"x16x1mm	F 
Hex-Head bolts - 8pcs	Washer - 8pcs	Laminate pad - 8pcs
G 	H 	I  ø7xø3.5x15mm
Handle screw - 4pcs	Damping hinge - 4pcs	Flat head screw - 48pcs
J  ø7xø3.5x15mm	K 	L  ø5/32"x25mm
Round head screw - 26pcs	Handle - 4pcs	Handle screw - 4pcs
M  4mm	N 	
Allen key - 1pc	Anti fall hardware - 1set	


STEP: 1




STEP: 2




A





4PCS







STEP: 3




B	C
	
2PCS	2PCS

STEP: 4




C	D	E
		
4PCS	4PCS	4PCS




STEP: 5




STEP: 6





STEP: 7


G	H	I
		
4PCS	4PCS	16PCS



* Please note that hinges G and H are different, please do not install them backwards.

STEP: 8

K	L
	
4PCS	4PCS



x2




STEP: 9

I




32PCS


Note: Please assemble the door according to the installation steps first. If the cabinet door is deviated, the internal hinge needs to be slowly adjusted to solve the problem.




Use the screws to adjust up or down





Use the screws to permanent






Use the screws to adjust left or right





Use the screws to adjust in or out



STEP: 10




STEP: 11



- Select the location to place the cabinet.
- Drill a hole in the dry wall to fit Anchor
Then included the Patch L with Long screw.
- Assembly the Patch L to the cabinet and
affix by Short screw.


x2	x1	x1	x1	x1

STEP: 12




- Place the cabinet into position so both mounting Patch are vertically in line.
- Put the Strap into hole of Patch L then tighten the steel wire.

STEP: 13



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

