




ASSEMBLY INSTRUCTIONS






You will need



approx. 1 hour



2 person




Place your product on a soft surface when assembling



Do you have questions about the
assembly of your furniture?

Contact your nearest Customer Service !

PANEL LAYOUT & HARDWARE LIST



	Antal	mm
1	1	1500*400*15
2	1	1500*400*15
3	1	590*399*15
4	1	590*399*15
5	1	590*382.5*15
6	2	735*264*5
7	2	735*264*5
8	2	380*80*15
9	2	726.5*80*15
10	1	729.5*143*16
11	1	729.5*143*16
12	1	729.5*193*16
13	1	729.5*193*16

	Antal	mm
14	1	729.5*242*16
15	1	729.5*242*16
16	2	350*100*15
17	2	350*100*15
18	2	671.5*100*15
19	2	350*160*15
20	2	350*160*15
21	2	671.5*160*15
22	2	350*200*15
23	2	350*200*15
24	2	671.5*200*15
25	6	336*60*15
26	6	679.5*343*5
27	4	h:115
28	1	h:125


A	B	C	D
E	F	G	H
I	J	K	L
M	N	O	O

Nr	Antal	mm
A	52	Ø6x35
B	52	Ø15x9.5
C	14	Ø8x30
D	6	350
E	1	Ø19xM6x15
F	6	120
G	2	6*30
H	24	15x15x9
I	24	Ø3x16
J	40	Ø4x35
K	62	Ø3.5x12
L	12	M6x25

Nr	Antal	mm
M	6	Ø7x50
N	1	4
O	4	Ø4x12
P	2	75x25x15

d is drawer slide.
CL for the left of cabinet,
CR for the right of cabinet;
DL for the left of drawer,
DR for the right of drawer.

Screwdrivers are not included in the accessories.





Assembly

Follow the step-by-step instructions

DON'T FULLY TIGHTEN THE SCREWS
BEFORE FINISHING ASSEMBLY.



1.





Ax6

Ⓐ x6	Ⓟ x2	Ⓢ x4	

2.




Ax4



Ⓐ x4	Ⓓ x3	Ⓚ x12	



3.




(A) x4

(D) x3


(K) x12






4.






(C) x12




5.





6.



7.




8.




Mx6

(M) x6	(N) x1
	


9.




10.





11.




12.




(B) x6




13.



$XX=YY=90^\circ$







hx24 ix24



If you have a gradienter in your home, you can use it to adjust the tilt angle of the dresser to keep them at 180° after installing them.





(h) x24	(i) x24			

14.




g x2	j x2				

15.







Ax12

(A) x12




16.







Ax12

(A) x12




17.





Ax12



(A) x12





18.





(B) x12




19.







20.





ⓐ x12





21.




22.





23.






(J) x12





24.






(B) x12









25.



26.









27.




ⓓ x6	Ⓚ x24	

28.



Ⓕ x6	Ⓚ x24	


29.



Note: fine-tune drawer up and down, please adjust the track



Maximum weight



DECORATE STYLISHLY AND SAFELY!

It is important to feel safe in your home , especially when you have children. Every year there are many accidents caused by falling furniture-accidents that could have been easily avoided. Here are some ways to keep your new furniture from tipping :



A form of anti rollover protection; A strap fixed to the bracket with bolts

Anchor

the furniture to the wall. Use the anti-tipping device that comes with the furniture (all furniture more than 75 cm high should be supplied with a anti-tipping device). Refer to the assembly instructions, based on the type of wall you have.

Preventing

a child from climbing on the furniture, or otherwise hanging on it.


Store

heavy objects as far down as possible, never in the the upper parts of the furniture. Remember that not all furniture is made to support heavy televisions, for example


- There is special media furniture for these.

WHICH SCREW TO USE?


1. Drywall with wooden studs: Fix the screw directly into the stud.
2. drywall without wooden studs: use plug with screw.
3. Solid concrete wall: Use plugs with screws.
4. Hollow concrete wall: Use folding plug/expander.




Träskruv



Plug with screw



Plug with screw



Folding plug/expander with screw

If you are in any doubt about which screws to use, contact a builders' merchant or hardware store.



A form of anti-tipping device; angle iron