

IMPORTANT INSTRUCTIONS DO NOT DESTROY

Blanket & Mattress Pad

TABLE OF CONTENTS

IMPORTANT INSTRUCTIONS.....2-3

SET UP PROCEDURES4

CONTROLLER FEATURES.....5

CARE INSTRUCTIONS.....6

TROUBLE SHOOTING.....7-8

IMPORTANT INSTRUCTIONS

WARNINGS AND SAFEGUARDS

To operate this warming product properly and safely, there are some critical safety precautions you need to follow. As with all electrical appliances, there is an inherent danger of overheating, fire or personal injury with the product if it is not used correctly. Please carefully read the following before using the warming product.

1. Do not use with generators, power converters, or inverters.
2. Do not tuck in the wired area of this bedding.
3. Do not tuck the product or supply cord in a sofa or other furniture. All portions of the blanket or controller should be visible at all times.
4. Do not route electrical cords between the mattress and box spring. Do not allow the cords to be pinched.
5. Do not use with rocking chairs, recliners, chairs with casters or wheels or other furniture subject to movement.
6. Never trap or pinch any of the electrical cords in any mattress way. Make sure the cords are never rested between the mattress and box spring.
7. The heated area of the warming blanket & mattress pad should always lie flat on top of the mattress to prevent overheating.
8. If the plug does not fit into your outlet, contact a qualified electrician, do not force plug into outlet.
9. Be sure that the power supply is used only on 120V, 60HZ Current Supply.
10. Make sure the cord from the controller to your heated product is connected and locked tightly.
11. NEVER use your blanket with an airbed, a pull-out sofa or mechanically adjusted bed.
12. You may use this electric blanket with any sheet, mattress pad or other blankets but never in combination with any other electrical heated products.
13. The warming products should never be folded, balled up or bunched in any way when in use. May result in overheating and/or permanent wrinkling of the fabric.

IMPORTANT INSTRUCTIONS

14. Be sure to read carefully the accompanying instruction booklet before using this bedding .
15. Never use pins in and around the warming product – They may damage the electric wiring.
16. Cats, dogs and other pets should always be kept away from the product, as a sharp claw may result in damage to the heating element.
17. Keep the controls always from drafty areas that may become damp or wet, such as an open window.
18. Always turn off when the warming product is not in use, either by turning off the controller or unplugging from the wall outlet.
19. Wrapping of the cord around the controls may damage the cord. Loop loosely when storing.
20. NEVER iron your warming product.
21. NEVER use dry cleaning products on this item. Cleaning solvents may damage the wiring insulation.
22. If improper operation of this bedding is observed, discontinue its use immediately and consult the manufacturer or the dealer regarding its repair.
23. Controller is not waterproof. do not immerse in water.
24. Check with your healthcare provider before using with a pacemaker or any medical devices

SET UP PROCEDURES

STEP 1

Place controllers near the head of the bed. Queen and King blanket or mattress pad include two controllers that operate independently. Cord should run from the controller under bed connecting to the end of the blanket or mattress pad at the foot of the bed.

STEP 2

Connect Power Cord Connect power cord to the blanket or mattress pad by matching the arrow on the power cord to the arrow on the connector. Once arrows are aligned, push cord into the connector until they are securely connected. You should feel it snap into position.



STEP 3

Plug Controller into the wall Once you have properly attached power cord to the connector, plug your heated blanket or mattress pad into the wall. Queen and King Sizes will have two power cords.

CAUTION:

- Do not plug main power cord into the wall outlet until you have completely set up your heated product per the instructions.
- Disconnect power cord from the wall before detaching controller cord from your heated product.
- Always make sure cords are not pinched between mattress, bed slats, furniture, wall, or any surface.
- This product has a polarized plug(one plug blade is wider than the other). To reduce the risk of electrical shock, if this plug does not fit in the outlet, reverse the plug. If it still does not fit, contact an electrician. Do not attempt to defeat this safety feature.




CONTROLLER FEATURES

CONTROLLER FUNCTION


1.Please connect the controller to the coupler on the blanket first then connect to the power. The LED on the controller will stop lighting after a few seconds then go into the standby mode.

2.In the standby mode, please press start key on the controller, then the product will start work on the default heat level 1(green light). If you want warmer feeling, you can keep pressing the start key, then the heated blanket will go into the next heat level .



TIME SETTING

The default the time setting of this blanket is 10 hours auto-off. If you turn off the product during using, the product will re-start the timer of 10 hours auto-off. Any changing of the heat setting will not affect the time setting.



CARE INSTRUCTIONS

Care and Cleaning OF YOUR HEATED BEDDING PRODUCT

We recommend washing before initial use.

Before Washing or Storing Your Heated Bedding Product:

1. Disconnect power cord from wall BEFORE detaching control cord from the heated product.
2. Ensure that no cords are still connected and none of the wires have worn through the fabric.
3. Carefully follow all washing instructions or your heated product may shrink and possibly cause a fire hazard.
 - DO NOT submerge control in water.
 - DO NOT dry clean your heated product, Dry cleaning solvents may damage the wires.
 - DO NOT use bleach or cleaning fluids.
 - DO NOT use a wringer.
 - DO NOT iron your heated product.
 - DO NOT use mothballs or sprays of any kind.
 - DO NOT reconnect the heated product or use it until it is COMPLETELY dry.
 - DO NOT wash or put into water the power cord or any of the product's cords.
 - DO NOT use analgesic cream in combination with your heated product.

Taking care of your heated product is easy and safe as long as you follow a few simple steps.

Machine Washing

1. Presoak the blanket/ mattress pad for 15 minutes in mild soap and cold water.
2. Wash in mild soap and cold water on the "delicate" or "gentle" cycle in the washer for two minutes. Remember, do not use bleach.
3. Rinse in fresh, cold water.
- 4 Spin dry in the washing machine. Then gently stretch to its original size

Machine Drying

Caution: Do not use commercial dryers or the dryers at your local Laundromat. They get too hot and would damage the wiring of the heated product.

1. Preheat the dryer on the "low" temperature setting for 2 minutes.
2. Place blanket/mattress pad into the dryer and tumble dry for 10 minutes at a low temperature.
3. Remove the blanket/mattress pad while it is still damp and gently stretch it to its original size.
4. Drape the heated product over a clothesline or a shower rod. DO NOT use clothespins
5. Heated product must be COMPLETELY dry before reconnecting the power plug or control plug.

Hand Drying

1. Gently stretch the blanket/mattress pad back to its original size.
2. Drape the heated product over a clothesline or hang over a shower rod. DO NOT use clothespins.
3. Heated product must be COMPLETELY dry before reconnecting the power plug or control plug.

TROUBLE SHOOTING

DRYING INSTRUCTIONS

NEVER USE COMMERCIAL DRYERS AT THE LAUNDROMAT-- THEY MAY BE EXTRA HOT AND COULD DAMAGE THE WIRING. DO NOT IRON. DO NOT PLUG IN UNTIL COMPLETELY DRY.

MACHINE DRY

To machine dry, put your product into a family washing machine and dryer on low heat below 40°C. Ensure that the textile has enough room to tumble freely. If blanket draws in during washing, while still damp gently stretch until it returns to its original size.

LINE DRY

You can line dry, simply by draping the warming product over two parallel clotheslines or a shower rod with the head and foot ends down. Do not reconnect warming products until they are completely dry. Do not use clothes pins that can pinch wires.

STORAGE

Store as you would any other bedding, folded in a dry place.

Q: The light on my controller does not light up.

A: Assure that all the wire connections are tight and that the power cord is connected to an “energized” socket (try a lamp to verify that the outlet is working properly)

Q: The controller is lit but the product does not heat up.

A: Test the product by folding the textile over on itself and turning on the controller. Ensure that controller lamp is lit. After approximately five minutes, carefully feel between the layers. Never leave the product turned on and folded up for more than a few minutes.

Q: I feel some warmth but not a lot. How warm should this product get?

A: This product will provide enough warmth to keep you quite comfortable even in an extremely cold room . You should spend several nights experimenting with the heat settings until you find your personal comfort level. This product is not like a heating pad(this amount of heat would be too hot to use all night long). In normal operation, will not feel hot to the touch.

TROUBLE SHOOTING

Q: Can I sit or lie on my electric product?

A: Just sitting or lying on the product will not harm it. Jumping on it or other similar abuse may damage it.

Q: Can I use bedspread or comforter over my electric product?

A: You normally will not need more warmth than this product will provide. However, you make use any bedding you wish with this blanket/M.P. except an Electric mattress pad, another electric blanket or a heating pad (overheating may occur).

Q: My product works fine but then seems to shut off.

A: The 10 hour automatic shutoff feature may have activated. Simply push the button again and your blanket /M.P. will heat for an additional ten hours or until you turn it off. If ten hours have not elapsed, check that all your connections are tight and the wall outlet is not turn off.

Q: Why is my controller warm?

A: A small amount of heat is produced when transferring power from the wall to the blanket. This warmth is completely normal and is nothing to be concerned about.

Q: My power supply cord sparked at the wall outlet when I plugged it in.

A: Yes, many electric appliances will sometimes “snap” due to the inrush of electricity when first plugged in. This is completely normal and nothing to be concerned about it.

WARRANTY AND CUSTOMER SUPPORT

If you need help regarding product issues, after-sales service, or other relevant problems, please contact us via Amazon customer service or official website.