


Assembly Instructions


30314 Accent Table

Product Issues? Please Call Us Before Contacting Your Retailer At 1-800-549-3300. Email customerservice@mshome.co, visit www.mshome.co


We can help with Assembly Issues, Part Requests, Damages, & All Other Product Related Questions




MSH-USA




15 min




Two People Required
for Assembly



Do Not Use Power Tools




Phillips Head
(Not Provided)



PARTS INCLUDED




- C1 Table Top x1
- C2 Leg x4
- C3 Shelf x1




Hardware Pack

A  Ø1/4"x30mm: 8pcs	B  4mm: 1pc	C  18*18*13: 4pcs	D  3.5*15: 8pcs
---	---	---	---


- 1 **A X 6**  **B X 1** 




- 2



3	CX 3 	DX 3 	
---	--	--	--





4	AX 2 	BX 1 	CX 1 	DX 1 
---	--	--	---	--



5

DX 4



6

