

# ASSEMBLY INSTRUCTIONS

#### **TOOLS REQUIRED**






### **ASSEMBLY RATING**



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



ja j	Are you missing anything?	Check out our Quick Tips!
	Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now an then!
	Should we send any replacements?	Prep Time!
	Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





#### Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





#### Suitable Location

Assembling near the area of the intended location is highly recommended.





#### Sufficient Space

Make sure you have enough space to move around during the assembly.





#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





#### Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

#### **END TABLE**





## **PARTS**





TABLE TOP 1pc





LEGS 4pcs



BOTTOM 1pc

#### **HARDWARE**

















ALLEN WRENCH 1pc


BOLT Ø5/16"x 2" 12pcs

LOCK WASHER Ø 5/16 12pcs

LOCK WASHER Ø 5/16 x 19mm 12pcs

#### **END TABLE**





## **PARTS**





TABLE TOP 1pc





LEGS 4pcs



BOTTOM 1pc

#### **HARDWARE**

















ALLEN WRENCH 1pc

BOLT Ø5/16"x 2" 12pcs


LOCK WASHER Ø 5/16 12pcs

LOCK WASHER Ø 5/16 x 19mm 12pcs

### **ASSEMBLY INSTRUCTIONS**

Remove drawer from case as shown Attach the Legs(#2) to Table Top (#1). Secure by Part #1 x 1pc using Bolt (#B) with Lock Washer (#D) and Flat Part #2 x 3pcs washer (#C) Allen wrench(#A). Hardware #A x 1pc Hardware #B x 6pcs Hardware #D x 6pcs Hardware #E x 6pcs 2 Part #1 x 1pc Part #2 x 1pc Part #3 x 1pc Hardware #A x 1pc Hardware #B x 6pcs Hardware #D x 6pcs Hardware #E x 6pcs Attach the bottom shelf (#3)to the leg (#2) and attach 4th leg to table top and bottom shelf .Using Bolt (#B) Lock washer (#C), Flat washer (#D) and Allen Wrench (#A). Put the drawer on case.

# **ASSEMBLY INSTRUCTIONS**



# ASSEMBLY COMPLETED



Please ensure the Furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

- Weep this handy!
  Please retain this instruction
  manual and any order-related
  information for future reference.
- Cift, don't drag!

  To avoid damage to product please always LIFT the product when transporting of adjusting the placement