










Assembly Instructions


Caution : You must read this before you proceed

Care & Maintenance







- ⊘  • Not for commercial use. For residential use only.
 - ⊘  • Do not put hot items directly on furniture surface.
 - ⊘  • Do not clean furniture with harsh cleansers or polish.
 - ✓  • To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 - ⊘  • Children should not climb or jump on the furniture.
 - ⊘  • Do not write on furniture without a padded barrier to protect the surface.
 - ✓  • To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 - ⊘  • Stains may be removed with mild soap solution and damp cloth.
-
- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in boxes for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.




Club Chair












Parts List

Label	Picture	Description	QTY
A		Left Armrest	1
B		Right Armrest	1
C		Back Support Bar	1
D		Seat Panel	1
E		Seat Cushion	1
F		Back Cushion	1

Hardware

Label	Picture	Description	QTY
①		Allen wrench	1
②		Bolt (M6*20MM)	3
③		Bolt (M6*40MM)	7

Assembly Preparation

Before Beginning Assembly:						
	A*1	B*1	C*1	D*1	E*1	F*1
			 ①*1	 ②*3	 ③*7	



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview



This Club Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Club Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Place Left Armrest(A) on the ground, as shown in picture above.

Attach Back Support Bar(C) to Left Armrest(A) using Bolt (2) with Allen Wrench (1)

Do not fully tighten the Bolt


Step 2



As shown in the picture, install the Seat Panel(D) to the Left Armrest(A), using Bolt (3) with Allen Wrench (1)

Do not fully tighten the Bolt


Step 3



As shown in the picture, install the Right Armrest(B) to the Back Support Bar(C) and Seat Panel(D) , useing Bolt (②) and (③) with Allen Wrench (①)

Do not fully tighten the Bolt

Step 4



Stand the Club Chair up.
Place the Club Chair on a LEVEL SURFACE.
Then, proceed to tighten all Bolts in a sequential manner.
When tightening the Bolts, tighten sequentially.

Put Back Cushion(F) and Seat Cushion(E) on the Club Chair.
Inspect it and make sure all parts are adequately connected.
Gently and carefully sit onto the Club Chair.
This will help to align all parts at all joints. Then get off the Club Chair, and in sequential manner, proceed to tighten all Bolts. When tightening the Bolts, tighten sequentially.
DO NOT tighten any Bolt fully and then move on to the next one.
This may cause the frame to warp.

If there are still wobbles, loosen the Bolts and execute this same process.

Note: This step is done best with the assistance of a second adult.

Your Club Chair is ready for use.

This Club Chair can only be used on a flat, level surface.