


USER'S MANUAL

NIX SERIES KITCHEN ISLAND WITH WHEELS



Guide of Manual

- ★ Thanks for your choice. We will do our best to provide customer service for everyone.
- ★ Please check to make sure all parts are included as stated when you unpack. If there are parts missing or wrong, please contact us, we will expeditiously provide reissue accessories, compensation or other services.
- ★ Instruction should be read carefully. But the manual may not cover every detail of all possible situations and steps. Please contact us if further information and help are needed. We will respond in a timely manner.
- ★ Please be patient that the other items are on the way if you buy more than one product.

Warning

- It's kindly advised to assemble this product on a carpeted floor to protect it from being scratched.
- Small parts are included. Please keep the product away from children while assembling. Do not let children play or jump on the product. Do not stand on the item or use as a step ladder.
- Please pay attention to the sharp corners during assembly.
 We recommend the use of gloves to prevent the undesired injury.
- Prior to use, please check to see if there's any loosening screw or part. Make sure that each screw and part is correctly installed and securely fastened.
- Usually it's unnecessary to use electric drill. Please at a low gear if you need.

Care and Maintenance

- Use a soft, clean cloth that will not scratch the surface when dusting.
- There's no need to use furniture polish. If you need, test it first in an inconspicuous area. Using solvents of any kind on your furniture may damage the finish. Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately. Gently blot the spill with a soft clean cloth to avoid rubbing.

Further Advice About The Furniture Care

- It is best to keep your furniture in a climate-controlled environment.
- We recommend to keep furniture from sunlight exposure to avoid possible surface damage.
- Following these important and helpful tips will help retain your furniture's performance even when it ages.
- Periodically (every 90 days) make sure the screws are fully tightened.

MAX WEIGHT CAPACITY: 150LBS / TABLE TOP 30LBS / DROP-LEAF TABLETOP DO NOT STAND ON THE ITEM

Part List & Assembly Instruction

- Make sure all parts are in the package.
 "+" in below list indicates that additional pieces are replacement part.

Parts List

		Γ	I
①x 1pc	②x 1pc	③x 1pc	4 x 1pc
Top board	Folding board	Side board	Middle board
⑤x 1pc Side board	<u>⑥</u> х 1рс	⑦х 1рс	® х 1рс
9 x 1pc	① x 1pc	① x 2pcs Back board	①x 2pcs
	0		. 0
13 x 2pcs	14x 2pcs Clapboard	①5 x 1pc	16 x 1pc

Parts List


① x 1pc	①8 x 1pc	①9 x 1pc	20x 1pc
②1) x 2pcs	22 x 1pc	23 x 1pc	24x 1pc
25 x 1pc	26 x 1pc	②7) x 1pc Door	28 x 1pc Door
29 x 1pc Bottom board	30 x 2pcs	(31) x 2pcs	32 x 2pcs
33 x 2pcs	34) x 2pcs	(35) x 2pcs	

Part List & Assembly Instruction

- Make sure all parts are in the package.
 "+" in below list indicates that additional pieces are replacement part.

Hardware List

A x 63+3pcs	B x 63+3pcs	C x 24+3pcs	D x 4pcs
Ø15x10mm	Ø6x35mm	Ø8x30mm	Ø28x25mm
E x 2pcs	F x 74+3pcs	G x 4pcs	H x 7pcs
M4x20mm	Ø3x15mm	50*40*18mm	45*36*5mm
=			
I x 2pcs	J x 2pcs	K x 2pcs	L x 20+3pcs
M4x14mm	40*15*12mm	35*10*1mm	Ø5x16mm
			(S) THIND THE S
M x 16+2pcs	N(N1+N2) x 4pcs	O x 8+1pcs	P x 1pc
Ø3x12mm	12"	Ø6x17mm	
	Es.		
Q x 63+3pcs	R x 3pcs	S x 2pcs	T x 16+1pcs
Ø20mm	2.5" Wheels	2.5" Wheels with brake	M6x35mm
			(a) Managaman
U x 8+2pcs	V x 6+1pcs	W x 4+1pcs	X x 8pcs
Ø4x25mm	M6x25mm	Ø13mm	14*11*9mm
(s)		0	0
Z x 2pcs	Screwdrive		
30*15*3mm			
~	Not Included		



Tighten the hardware to 100% at each step of installation.

