


ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Allen Wrench
(Included)



Screwdriver
(Not Included)



2 - People

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.




Save the instructions and store
any supplied tools for later
maintenance.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

TWIN SIZE BED




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1 1pc




HEADBOARD

2 1pc




HEADBOARD LEG - L

3 1pc




HEADBOARD LEG - R

4 1pc




FOOTBOARD

5 2pcs




FOOTBOARD SUPPORT

6 1pc




FOOTBOARD LEG - L

7 1pc




FOOTBOARD LEG - R

8 2pcs



SIDE RAIL


9 4pcs



BED SLAT


HARDWARE

A 8pcs




BOLT M8 x 16MM

B 8pcs




BOLT M8 x 40MM

C 8pcs




LOCK WASHER M8

D 8pcs



FLAT WASHER M8

E 8pcs



BOLT M6 x 35MM

F 8pcs



LOCK WASHER M6

G 8pcs



FLAT WASHER M6

H 1pc



ALLEN KEY M5

I 1pc



ALLEN KEY M4

J 8pcs























CSK SCREW M4 x 32MM

K 1pc



ADAPTOR

packed in 2 cartons



Carton	Designation			Hardware	
	Twin Size Headboard	1		 A x 8pcs  B x 8pcs  C x 8pcs  D x 8pcs  E x 8pcs  F x 8pcs  G x 8pcs  H x 1pc  I x 1pc  J x 8pcs  K x 1pc	
	Headboard Leg-L	1			
	Headboard Leg-R	1			
	Footboard	1			
	Footboard Support	2			
	Footboard Leg-L	1			
	Footboard Leg-R	1			
	Slat	4			
	Twin Size Side Rails	2			

ASSEMBLY INSTRUCTIONS

1

- Part (#1) x 1pc
- Part (#2) x 1pc
- Part (#3) x 1pc
- Hardware (#B) x 8pcs
- Hardware (#C) x 8pcs
- Hardware (#D) x 8pcs
- Hardware (#H) x 1pc



Align the headboard post (#2L,#3R) to the headboard (#1). Use allen key (#H) to attach headboard post (#2L,#3R) to the headboard (#1) by using screw assembly of screw (#B) with lock washer (#C) and flat washer (#D).



2

- Part (#4) x 1pc
- Part (#5) x 2pcs
- Part (#6) x 1pc
- Part (#7) x 1pc
- Hardware (#E) x 8pcs
- Hardware (#F) x 8pcs
- Hardware (#G) x 8pcs
- Hardware (#I) x 1pc

Align footboard leg (#6L,7R) to the footboard (#4) as shown in the diagram. Use allen key (#I) to secure the footboard support (#5) to the footboard by using screw (#E) with lock washer (#F) and flat washer (#G).




ASSEMBLY INSTRUCTIONS

3

- Part (#1) x 1pc
- Part (#2) x 1pc
- Part (#3) x 1pc
- Part (#4) x 1pc
- Part (#8) x 2pcs
- Hardware (#A) x 8pcs
- Hardware (#H) x 1pc

3-2 Hook screw plate attached on the side rail (#8) onto bolt (#A).


3-3 Use allen key to tighten the bolt (#A) and secure the side rail (#8) to the headboard post (#3) and footboard (#4).



4

- Part (#8) x 2pcs
- Part (#9) x 4pcs
- Hardware (#J) x 8pcs


Extend the slats (#9) over the side rail (#8) and secure by using screw (#J). Tighten with screwdriver (not included).




ASSEMBLY INSTRUCTIONS

5

Hardware #K x 1pc



6



- ✓ **Keep this handy!**
Please retain this instruction manual and any order-related information for future reference.
- ✓ **Lift, don't drag!**
To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.