



ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not included)



(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!



Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.


Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


KING BED



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS




HARDWARE









HARDWARE INSIDE HEADBOARD



HARDWARE INSIDE FOOTBOARD SIDERAIL



packed in 2 cartons


Carton	Description	Part		Hardware
	HEADBOARD	1	 X1	 A x10pcs  B x10pcs  C x10pcs  D x1pc  E x1pc
	HEADBOARD POST (LEFT)	2	 X1	
	HEADBOARD POST (RIGHT)	3	 X1	
	SIDERAIL	4	 X2	 F x28pcs  G x8pcs  H x8pcs  I x8pcs  J x1pc  K x1pc
	FOOTBOARD	5	 X1	
	CENTER RAIL	6	 X4	
	CENTER RAIL SUPPORTER	7	 X8	
	FOOTBOARD LEG	8	 X2	
	SLATS	9	 X2	

ASSEMBLY INSTRUCTIONS

1

Part ① x1pc
Part ② x1pc
Part ③ x1pc


Align the headboard post (#2L,#3R) to the headboard (#1).



2

Part ① x1pc
Part ② x1pc
Part ③ x1pc
Hardware ④ x10pcs
Hardware ⑤ x10pcs
Hardware ⑥ x10pc
Hardware ⑦ x1pc


Use allen key (#D) to attach headboard post (#2L,#3R) to the headboard (#1) by using screw assembly of screw (#A) with lock washer (#B) and flat washer (#C).



ASSEMBLY INSTRUCTIONS

3


Part ⑤ x1pc
 Part ⑧ x2pcs
 Hardware ⑥ x2pcs
 Hardware ⑦ x2pcs
 Hardware ⑧ x2pcs
 Hardware ⑨ x1pc



Use allen key (#J) to attach footboard leg (#8) to footboard (#5) by using screw assembly of screw (#G) with lock washer (#H) and flat washer (#I).

4

Part ① x1pc
 Part ④ x2pcs
 Part ⑤ x1pc
 Hardware ⑫ x1pc



4-2 Hook screw plate attached on the side rail (#4) onto the Truss screws and use allen key to tighten the Truss screw and secure the side rail (#4) to the headboard post (#2, #3) and footboard (#5).

4-1 Loosen the Truss screws on the headboard post (#2L, #3R) as well as the Truss screws on the footboard panel (#5).

ASSEMBLY INSTRUCTIONS


5

Part ⑥ x4pcs

Part ⑦ x8pcs

Part ⑨ x2set

Align the center rail (#6) on the slats (#9) and secure together by twisting the center rail support (#7) until tight.



6

Part ⑨ x2set

Hardware ① x28pcs

Hardware ② x2pcs


Hardware ③ x2pcs

Hardware ④ x2pcs


Hardware ⑤ x1pc

6-2 Extend the slats (#9) over the side rail (#4) and secure by using screw (#1). Tighten with screwdriver(not included).

Touch Controller



6-1 Use allen key (#J) to attach the footboard leg (#8) to the side rail (#4) by using screw assembly of screw (#G) with lock washer (#H) and flat washer (#I).




ASSEMBLY INSTRUCTIONS

7

Hardware ⑤ x1pc

Connect the attached power connector on the headboard to the power adaptor (#E).



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.