



ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED



Screwdriver
(Not included)



Allen Wrench



2 - People

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!




Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

QUEEN BED




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1 1pc




HEADBOARD PANEL
TOP

2 1pc




HEADBOARD PANEL
BOTTOM

3 3pcs




HEADBOARD
SUPPORTER

4 2pcs




SIDERAIL

5 1pc




FOOTBOARD

6 2pcs




CENTER RAIL

7 4pcs



CENTER RAIL
SUPPORTER

8 2set




SLATS

HARDWARE

HARDWARE INSIDE HEADBOARD

A 30pcs



JCBC M6 X 35mm

B 30pcs



Lock Washer

C 30pcs



Flat Washer

D 1pc



Allen Key M4

E 1pc



Adaptor

HARDWARE INSIDE FOOTBOARD SIDERAIL

F 28pcs









TRUSS HD C/B
M4 X 25mm

G 1pc



Allen Key M5

packed in 2 cartons

Carton	Description	Part	Hardware
	HEADBOARD PANEL TOP	(1)	 X1
	HEADBOARD PANEL BOTTOM	(2)	 X1
	HEADBOARD SUPPORTER	(3)	 X3
	SIDERAIL	(4)	 X2
	FOOTBOARD	(5)	 X1
	CENTER RAIL	(6)	 X2
	CENTER RAIL SUPPORTER	(7)	 X4
	SLATS	(8)	 X2

ASSEMBLY INSTRUCTIONS

1

Part ① x1pc

Part ② x1pc

Part ③ x3pcs


Hardware ④ x30pcs

Hardware ⑤ x30pcs

Hardware ⑥ x30pcs

Hardware ⑦ x1pc

Use Allen Key (#C) to attach Headboard Supporter (#3) to Headboard Panel Top (#1) and Headboard Panel Bottom (#2) by using JCBC screw (#A) with Lock Washer (#B) and Flat Washer (#C).




2

Part ⑥ x2pcs

Part ⑦ x4pcs

Part ⑧ x2set


Put the Center Rail (#6) on Slats (#8). Then take the Center Rail Supporter (#7) insert in the hole as in the picture and twist until tight.



ASSEMBLY INSTRUCTIONS


3

Part ① x1pc
Part ④ x2pcs
Part ⑤ x1pc
Hardware ⑥ x1pc



4


Part ⑧ x2set
Hardware ⑥ x28pcs





ASSEMBLY INSTRUCTIONS

5

Hardware (E) x1pc




6



Touch Dimmer Switch

Function: Located in the front of the headboard right facing. A quick tap will turn the light ON and OFF, a longer touch will adjust the brightness.

Remark :



Please peel to remove Protection Film

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.