ASSEMBLY INSTRUCTION ITEM NO: 194S1011BRW/DGY-1 ACCENT CHAIR




Hardware set is located inside the carton for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.


Component list

| No | Drawing | Qty | Description |
|----|----------------|-----|--------------------------------|
| А | | 1 | Chair Seat |
| В | | 1 | Chair Back |
| С | | 1 | Back Cushion |
| D | | 1 | LSF Armrest |
| E | | 1 | RSF Armrest |
| F | (a))))))))))) | 8 | Bolts 5/16"*38mm |
| G | | 8 | Flat Washers Ø19*Ø8.5*1.5mm |
| Н | | 8 | Lock Washers 5/16"*1.3mm |
| I | | 1 | Alen Wrench M4*75*35mm |


Step #1




Step #2




Step #3



Step #4



Step #5



Care Instruction for Faux Leather Furniture:

In order to maintain the original appearance of your faux leather Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage faux leather.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connection are tight, Re-tighten if necessary



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.