
TOOLS REQUIRED










2 - People

ASSEMBLY RATING



EASY DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?	Prep Time!
Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.






Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.






Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

KING BED

PARTS



HARDWARE








D 6pcs









BOLT M8 x 20MM

BOLT M6 x 15MM

BOLT M6 x 35MM

BOLT M6 x 50MM



F 14pcs













SPRING WASHER M6 x 12MM



FLAT WASHER M6 x 19MM



ALLEN KEY M5

ALLEN KEY M4





CSK SCREW M4 x 32MM **SPANNER 17MM**

1

Part #1) x 1pc

Part (#2) x 1pc


Part (#3) x 1pc

Hardware #D x 6pcs

Hardware (#E) x 6pcs

Hardware (#F) x 6pcs

Hardware (#H) x 1pc




2

Part (#4) x 1pc

Part (#5) x 2pcs

Hardware (#B) x 4pcs

Hardware (#H) x 1pc



3

Part (#6) x 1pc

Part (#7) x 2pcs


Part (#8) x 2pcs

Hardware #C x 8pcs

Hardware (#E) x 8pcs

Hardware (#F) x 8pcs

Hardware #H x 1pc



4

Part #2 x 1pc

Part (#3) x 1pc


Part (#4) x 1pc


Part (#7) x 2pcs


Part #8 x 2pcs

Hardware #A x 8pcs


Hardware (#G) x 1pc









Part #11 x 2pcs
Hardware #1 x 1pc




9





10



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screw are properly tightened and secured.

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.