


ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED




(Included)

Allen Wrench



2 - People



ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.



After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DINING TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.

PARTS

1 1pc






TABLE TOP

2 2pcs



TRIANGLE WOOD

3 1pc



HORIZONTAL WOOD

4 4pcs





TABLE LEG

HARDWARE

A 12pcs




JCBB BOLT
M8 x 45MM

B 16pcs




LOCK WASHER
M8

C 16pcs



FLAT WASHER
M8

D 1pc



ALLEN KEY
M5

E 4pcs




HEX BOLT
M8 x 50MM

F 1pc



SPANNER

G 10pcs




WOOD DOWEL
M10 x 30MM

ASSEMBLY INSTRUCTIONS

1

Part (3) x 1pc
Part (4) x 4pcs
Hardware (G) x 10pcs


Prepare horizontal wood (#3) and leg (#4) by inserting the dowels (#G) into the pre-drilled holes as shown in the diagram.



2

Part (2) x 2pcs
Part (4) x 4pcs
Hardware (A) x 8pcs
Hardware (B) x 8pcs
Hardware (C) x 8pcs
Hardware (D) x 1pc

Align the legs (#4) to the sides of the triangle wood (#2) and by using allen key (#D) secure using bolt (#A) with lock washer (#B and flat washer (#C).



ASSEMBLY INSTRUCTIONS

3

Part ③ x 1pc



Hardware ① x 4pcs

Hardware ② x 4pcs

Hardware ③ x 4pcs

Hardware ④ x 1pc

Align the horizontal wood (#3) to the triangle wood (#2) and with allen key (#4) secure by using bolt (#1) with lock washer (#2) and flat washer (#3).



4

Part ① x 1pc



Hardware ⑤ x 4pcs

Hardware ⑥ x 4pcs

Hardware ⑦ x 4pcs

Hardware ⑧ x 1pc


Align the legs to the table top (#1) and with spanner (#8) secure using hex bolt (#5) with lock washer (#6) and flat washer (#7).



ASSEMBLY INSTRUCTIONS

5

1 pc



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.