


ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED




(Included)

Allen Wrench



2 - People



ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.



After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DINING TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.

PARTS

① 1pc




TABLE TOP

② 1pc




TABLE LEG SUPPORT

③ 2pcs




TABLE LEG - SHORT

④ 2pcs





TABLE LEG - LONG


HARDWARE

A 16pcs




JCBB BOLT
M8 x 30MM

B 20pcs




LOCK WASHER
M8

C 20pcs



FLAT WASHER
M8

D 1pc



ALLEN KEY
M5

E 4pcs




HEX BOLT
M8 x 45MM

F 1pc




SPANNER

G 8pcs



WOOD DOWEL
M10 x 30MM

H 4pcs



METAL PLATE



ASSEMBLY INSTRUCTIONS

1

Part (2) x 1pc

Hardware (G) x 8pcs

Prepare table leg support (#2) by inserting wood dowel (#G) as shown in the diagram.



2

Part (3) x 2pcs

Part (4) x 2pcs


Hardware (A) x 8pcs

Hardware (B) x 8pcs


Hardware (C) x 8pcs

Hardware (D) x 1pc


Hardware (H) x 4pcs



Fix Metal Plate follow this line



With allen key (#D) attach metal plate (#H) to the short/long table leg (#3) and (#4) by using bolt (#A) with lock washer (#B) and flat washer (#C).




ASSEMBLY INSTRUCTIONS

3

- Part (2) x 1pc
- Part (4) x 2pcs
- Hardware (B) x 4pcs
- Hardware (C) x 4pcs
- Hardware (E) x 4pcs
- Hardware (F) x 1pc

Align the long table leg (#4) to the long side of the table leg support (#2) and with spanner (#F) start inserting hex bolt (#E) with lock washer (#B) and flat washer (#C).




Do not tighten these Hex Bolt

4

- Part (1) x 1pc
- Part (2) x 1pc
- Part (4) x 2pcs
- Hardware (A) x 4pcs
- Hardware (B) x 4pcs
- Hardware (C) x 4pcs
- Hardware (D) x 1pc

Align the metal plates on the long table leg (#4) to table top (#1) and start inserting bolt (#A) with lock washer (#B) and flat washer (#C) by using allen key (#D).



Do not tighten these JCBB Bolt

ASSEMBLY INSTRUCTIONS

5

Part ① x 1pc

Part ② x 1pc

Part ③ x 2pcs

Part ④ x 2pcs

Hardware ① x 8pcs

Hardware ② x 12pcs





Hardware ③ x 12pcs

Hardware ④ x 1pc

Hardware ⑤ x 4pcs


Hardware ⑥ x 1pc

Align the short table leg (#3) to the short sides of the table leg support (#2) and with spanner (#F) start inserting hex bolt (#E) with lock washer (#B) and flat washer (#C). Attach the metal plates on the short table leg (#3) to table top (#1) and start inserting bolt (#A) with lock washer (#B) and flat washer (#C) by using allen key (#D).



Tighten all JCBB Bolt and Hex Bolt

6



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screw are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.




Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not Included)



(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.




Save the instructions and store
any supplied tools for later
maintenance.



After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


DINING SIDE CHAIR



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.


PARTS

1 1pc



BACK PANEL

2 1pc



CUSHION SEAT

3 1pc



FRONT LEG - LEFT


4 1pc



FRONT LEG - RIGHT


HARDWARE

A 8pcs



JCBC BOLT
M6 x 20MM

B 4pcs



JCBC BOLT
M6 x 50MM

C 12pcs



LOCK WASHER
M6

D 4pcs



FLAT WASHER
M6

E 1pc





ALLEN KEY
M4

ASSEMBLY INSTRUCTIONS

1

Attach the left/right front leg (#3) and (#4) to the cushion seat (#2) with allen key (#E) and by using bolt (#A) with lock washer (#C).



- Part (2) x 1pc
- Part (3) x 1pc
- Part (4) x 1pc
- Hardware (A) x 8pcs
- Hardware (C) x 8pcs
- Hardware (E) x 1pc



2


Align and attach the back panel (#1) to the cushion seat (#2) with allen key (#E) secure by using bolt (#B) with lock washer (#C) and flat washer (#D).

- Part (1) x 1pc
- Hardware (B) x 4pcs
- Hardware (C) x 4pcs
- Hardware (D) x 4pcs
- Hardware (E) x 1pc



ASSEMBLY INSTRUCTIONS

3



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.