

TOOLS REQUIRED






ASSEMBLY RATING



The Assembly Rating is a 5-point system howing the level of effort needed to assemble a specific product.



Are you missing anything?	F)	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.		We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	_	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.
֡	Should we send any replacements? Are there any irregularities or flaws in the	Double-check all parts, hardware and accessories listed are all acccounted for. Should we send any replacements? Are there any irregularities or flaws in the

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SQUARE TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS





TABLE TOP 1pc 2



TOP MENDING PLATE 1pc

(3



LEFT LEG 2pcs 4



RIGHT LEG 2pcs

HARDWARE





BOLT Ø5/16" x 1-1/2" 12pcs B



LOCK WASHER Ø5/16" 12pcs (C




FLAT WASHER Ø5/16" 12pcs





ALLEN WRENCH 5mm 1pc


Exploded View




packed in 2 cases

Carton	Disignation	Part	Hardware
	Table Top		
	Top Mending Plate		
	Left Leg		A x 12pcsB x 12pcs
	Right Leg		C x 12pcs D x 1pc

Part (3) x 2pcs Part 4 x 1pc D Hardware (A) x 4pcs Hardware (B) x 4pcs Α Hardware © x 4pcs В Hardware (D) x 1pc (See ... 3 3 Part 4 x 1pc Hardware (A) x 4pcs Hardware (B) x 4pcs Hardware (C) x 4pcs Hardware (D) x 1pc -D





This product is intended for RESIDENTIAL USE ONLY and not for commercial use.