


# ASSEMBLY INSTRUCTION

ITEM NO. N715P212201

Dining Bench



# **ASSEMBLY INSTRUCTION**

ITEM NO. N715P212201

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners

# ASSEMBLY INSTRUCTION

ITEM NO. N715P212201




# ASSEMBLY INSTRUCTION

ITEM NO. N715P212201


## Part List

A




TOP BENCH (1pc)

B



LEG (2pcs)

C




SUPPORT RAIL (1pc)

# ASSEMBLY INSTRUCTION

ITEM NO. N715P212201

## Hardware List


1



Ø5/16"\*L50mm

BOLT (8pcs)


2



Ø5/16"\*13mm

LOCK WASHER (8pcs)


3



Ø5/16"\*19mm

FLAT WASHER (8pcs)

4




4mm





ALLEN KEY (1pc)

# ASSEMBLY INSTRUCTION


ITEM NO. N715P212201





## STEP 1 :



BOLT	LOCK WASHER	FLAT WASHER	ALLEN KEY
Ø5/16**50mm	Ø5/16**13mm	Ø5/16**19mm	4mm
			
① x 2	② x 2	③ x 2	④ x 1

## STEP 2 :



BOLT	LOCK WASHER	FLAT WASHER	ALLEN KEY
Ø5/16**50mm	Ø5/16**13mm	Ø5/16**19mm	4mm
			
① x 6	② x 6	③ x 6	④ x 1

# ASSEMBLY INSTRUCTION

ITEM NO. N715P212201

COMPLETE

