


ASSEMBLY INSTRUCTION

ITEM NO. N715P212200

Dining Table



ASSEMBLY INSTRUCTION

ITEM NO. N715P212200

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners

ASSEMBLY INSTRUCTION

ITEM NO. N715P212200




ASSEMBLY INSTRUCTION

ITEM NO. N715P212200

Part List

A



B



TABLE TOP (1pc)

LEFT LEG (2pcs)

C




RIGHT LEG (2pcs)

ASSEMBLY INSTRUCTION

ITEM NO. N715P212200

Hardware List


1



Ø5/16"*L50mm

BOLT (12pcs)


2



Ø5/16"*13mm

LOCK WASHER (12pcs)


3



Ø5/16"*19mm

FLAT WASHER (12pcs)

4




4mm





ALLEN KEY (1pc)

ASSEMBLY INSTRUCTION


ITEM NO. N715P212200





STEP 1 :



BOLT	LOCK WASHER	FLAT WASHER	ALLEN KEY
Ø5/16**50mm	Ø5/16**13mm	Ø5/16**19mm	4mm
			
① x 6	② x 6	③ x 6	④ x 1

STEP 2 :



BOLT	LOCK WASHER	FLAT WASHER	ALLEN KEY
Ø5/16**50mm	Ø5/16**13mm	Ø5/16**19mm	4mm
			
① x 6	② x 6	③ x 6	④ x 1

ASSEMBLY INSTRUCTION

ITEM NO. N715P212200

COMPLETE

