

















# ASSEMBLY INSTRUCTIONS

## MIRRORED BAR CART WITH SHELF

<b>A</b>	Large Mirror	<b>B</b>	Small Mirror	<b>C</b>	Top Frame
					
	2pcs		2pcs		1pc
<b>D</b>	Bottom Frame	<b>E</b>	Shelf Frame - E	<b>F</b>	Shelf Frame - F
					
	1pc		1pc		1pc
<b>G</b>	Large Panel - G	<b>H</b>	Large Panel - H	<b>I</b>	Small Panel
					
	1pc		1pc		1pc
<b>J</b>	Caster 1.5"	<b>K</b>	Caster With Brake 1.5"	<b>L</b>	Bolt 1/4" x 1"
					
	2pcs		2pcs		16pcs
<b>M</b>	Spring Washer 1/4"	<b>N</b>	Allen Wrench 1/4"	<b>O</b>	Spanner 12mm
					
	4pcs		1pc		1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**


**1**

Attach the Shelf Frame (E & F) to the Small Panel (I) using Bolt (L) with the Allen Wrench (N).




**2**


First, attach the Large Panel (G & H) to the assembled Shelf Frame (E & F). Next, attach the Top Frame (C) and the Bottom Frame (D) to the Large Panel (G & H) using Bolt (L) with the Allen Wrench (N) for both steps.



- 3** Attach the Caster (J) and the Caster with Brake (K) to the bottom of the Bottom Frame (D) using Spring Washer (M) with the Spanner (O). The Casters can be installed in any positions for convenient use.



- 4** Stand the Bar Cart upright. Place the Large Mirror (A) onto the Top & Bottom Frame (C & D) respectively. Then place the Small Mirror (B) onto the Shelf Frame (E & F) respectively.



### Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.