


Children have died from furniture tipover. Fixed wall device have been included with this product; you must install the fixed wall device according to these instructions in order to minimize the risk of furniture. If you have any questions about this product or the Fixed wall device, please contact us immediately.


Never allow children to climb or hang on furniture, including drawers or cabiner doors.


In addition to installing the restrains, to help prevent tip-over.

- 1. Never put a TV or other heavy objects on top of this product.
- 2. Do not stand on the product.















## Hardware installation demonstration


NOTE: Please make sure "A"hardware tightened and can't be pulled out!


















B\*12


Put B on board 2910









Put B on board 201011






**x2** 

	A*8
×	B*8
	F*2
Cil Service Control of the Control o	G*2
	H*8
	J*2
<b>Examination</b>	K*4
	N*8





Q\*1

## **END**