


Assembly Instructions

Caution: You must read these Assembly Instructions before you proceed.










Please look into the Seat Panel for hardware packs and legs.

LOVESEAT






Caution: This Loveseat is NOT a TOY.
Keep your child/children at bay during the assembly process.
Whenever moving/lifting the Loveseat and to prevent damage to the Loveseat,
two adults are required to execute these actions.

Part List


Label	Picture	Description	Qty
A		Seat Panel	1
B		Backrest Panel	1
C		Right Leg	1
D		Left Leg	1
E		Cross Bar - 1	1
F		Cross Bar - 2	1
G		Cross Bar - 3	1
H		Seat Cushion	1
I		Back Cushion	2

Hardware:

No.	Picture	Description	Qty
①		Bolt (M6x20)	5
②		Bolt (M8x35)	11
③		Allen Wrench M4	2

Assembly Preparation

Before Beginning Assembly:



☑ Read instructions, cover to cover.



☑ Have 2 adults on hand for assembly.



☑ Do not assemble on flooring or carpet.




☑ Assemble on a clean non-marring surface (packing foam).



☑ Save all packaging until finished.


Assembly Steps

Overview




This Loveseat has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Loveseat parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1:



Unpack and place all parts on a clean, non-marring surface.

Step 2:




Place Right Leg (C), Left Leg (D) and Cross Bar 1,2,3 (E)(F)(G) on a clean, non-marring surface.

Insert tenons on Right Leg (C) and Left Leg (D) into the mortises of Cross Bar 1,2,3 (E)(F)(G) as shown above.

Attach Right Leg (C) and Left Leg (D) into the mortises of Cross Bar 1,2,3 (E)(F)(G) using Bolt(②) with Allen Wrench(③) as shown in picture above.

DO NOT fully tighten the Bolts.


Step 3:



Insert Seat Panel (A) into assembled parts in Step 2 using Bolt(②) with Allen Wrench(③) as shown in picture above.

DO NOT fully tighten the Bolts.

Step 4




Insert tenons on Backrest Panel (B) into the mortises of Right Leg (C) and Left Leg (D) as shown above.

Attach Backrest Panel (B) into the mortises of Right Leg (C) and Left Leg (D) using Bolt(①) with Allen Wrench(③) as shown in picture above.

DO NOT fully tighten the Bolts.

Step 5:



Place Seat Cushion (H) by affix the Magic Tape Straps, and Back Cushion (I) onto Seat Panel (A).

Then EXERT pressure, floorwards onto the Loveseat with both hands.

This pressure will help the Loveseat reach full alignment at all joints.










In a sequential manner, gradually tighten all Bolts at all joints until evenly secured.

Inspect the Loveseat and make sure all parts are adequately connected.

Your Loveseat is ready for use.

This Loveseat can only be used on a flat, level surface.

Care & Maintenance

-  Do not put hot items directly on furniture surface
 -  Do not clean furniture with harsh cleansers or polish.
 -  To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 -  Children should not climb or jump on the furniture.
 -  Do not write on furniture without a padded barrier to protect the surface.
 -  To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 -  Not for commercial use. For residential use only .
 -  Stains may be removed with mild soap solution and damp cloth.
-
-  Dust and pick-up spills using a clean, non-colored, lint-free cloth .