


ASSEMBLY INSTRUCTIONS

ITEM NO.N715P236865,N715P236866

Dining Table



ASSEMBLY INSTRUCTIONS

ITEM NO.N715P236865,N715P236866

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTIONS

ITEM NO.N715P236865,N715P236866



ASSEMBLY INSTRUCTIONS

BOX 1 - ITEM NO.N715P236865

Part List

Ⓐ




TABLE TOP BETWEEN (1pc)

Ⓑ





TABLE TOP SIDE (1pc)

Ⓒ




PANEL TOP LEG (1pc)

ASSEMBLY INSTRUCTIONS

BOX 2 - ITEM NO.N715P236866

Part List

Ⓓ



LEG (1pc)

Ⓔ




BOTTOM STRETCHER (4pcs)

ASSEMBLY INSTRUCTIONS

ITEM NO.N715P236865

Hardware List


①



Ø 5/16" x 40 mm

BOLT (12 pcs)


②



Ø 5/16" x 55 mm

BOLT (12 pcs)


③



Ø5/16" x 13 mm

LOCK WASHER (24 pcs)

④



Ø5/16" x 19 x 2 mm

FLAT WASHER (24 pcs)

⑤




4 mm

ALLEN KEY (1 pc)


ASSEMBLY INSTRUCTIONS

ITEM NO.N715P236865,N715P236866

STEP 1:




STEP 2:




ASSEMBLY INSTRUCTIONS

ITEM NO.N715P236865,N715P236866

STEP 3:



STEP 4:




BOLT Ø 5/16" x 40 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16"x19x2 mm	ALLEN KEY 4 mm
			
① x 8	③ x 8	④ x 8	⑤ x 1



ASSEMBLY INSTRUCTIONS

ITEM NO.N715P236865,N715P236866

STEP 5:



COMPLETE



Adjust Leveler = 8 pcs