
ASSEMBLY INSTRUCTION

BAR STOOL



Please carefully unpack and identify each component before beginning assembly. Before you begin, please refer to parts list to make sure that you have all parts. Please take care when assembling the unit and always place the parts on a clean, soft surface. If you require assistance with assembly or parts, please call 888-357-7263.

Get social with us and discover more about our products, tips and exclusive discounts!












PRE-ASSEMBLY PREPARATION

• CAUTION: Assembly will require at least 2 adults. DO NOT use power tools. Please inspect all items BEFORE assembly. If for any reason you need to return this item, please kindly return it in it's original packaging.

WARNING!

- 1. DO NOT let any sharp objects touch or rub the surface of the product.
- 2. When assembling, do not let children play around the working area.
- 3. DO NOT tighten all bolts and screws completely until the entire unit has been assembled and set up.
- 4. DO NOT USE if this product become damaged, and/or components are broken or missing.
- CARE AND CLEANING: DO NOT scratch or chip the finish. DO NOT use abrasive chemicals for cleaning. Clean with mild soap on a soft rag. Rinse and dry thoroughly.
- MAINTENANCE: Please periodically check all fittings and re-tighten as necessary.




STEP-BY-STEP ASSEMBLY


PLEASE CAREFULLY UNPACK AND IDENTIFY EACH COMPONENT BEFORE BEGINNING ASSEMBLY. BEFORE YOU BEGIN, PLEASE REFER TO PARTS LIST TO MAKE SURE THAT YOU HAVE ALL PARTS.

Tips: Please do not fully tighten the bolts until the chair is assembled, 70% tightness is sufficient to leave room for adjustments.


Connect the legs (G) with leg connectors (E&F), align the screw holes as STEP 1 shown in below diagram.




STEP 2 Attach the legs (G) to leg connectors (E&F) by using bolts (I), tighten to 70% by alley key (N) as shown in below diagram.




Attach the leg connector (F) to leg connector (E) by using bolts (K), tighten to 70% STEP 3 by alley key (N) as shown in below diagram.




STEP 4 Attach the back frames (C) to seat cushion (B) by using bolts (J), tighten to 70% by alley key (N) as shown in below diagram.




STEP 5 Attach the back frames (C) to back cushion (A) by using bolts (J), tighten to 70% by alley key (N) as shown in below diagram.




In this step please tighten all bolts (J) 100% by alley key (N) as shown in STEP 6 below diagram.




Attach the swivel plate (D) to seat cushion (B) by using bolts (M) and using STEP 7 bolts (L), tighten to 100% by alley key (N) as shown in below diagram.




STEP 8 Attach the leg frame to swivel plate (D) by using bolts (M), tighten to 70% by alley key (N) as shown in below diagram.




Use your body weight to adjust balance of this bar stool. STEP 9



STEP 10 Attach the footrest(H) to legs (G) by using bolts (K), tighten to 70% by alley key (N) as shown in below diagram.




STEP 11 In this step please tighten all bolts (L,M,K) 100% by alley key (N) as shown in below diagram.



STEP 12 Please recheck and ensure 100% tighten all the bolts in this step. After initial assembly, the product may acclimate to its new environment. Please ensure all bolts are still securely tightened.

Additional note about safety:

Bolts may loosen during normal everyday use. They should be periodically inspected and re-tightened to prevent damage or injury. Remember to save your allen key to use to tighten.



glitzhome®

Glitzhome ,LLC.

Toll free 888-357-7263 customerservice@glitzhome.com