












Assembly Instructions


Caution : You must read this before you proceed

Care & Maintenance







- | | |
|---|--|
| ⊘  | • Not for commercial use. For residential use only. |
| ⊘  | • Prolonged exposure to rain may cause rusting which can stain floors. |
| ⊘  | • Do not put hot items directly on furniture surface. |
| ⊘  | • Do not clean furniture with harsh cleansers or polish. |
| ✓  | • To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended. |
| ⊘  | • Children should not climb or jump on the furniture. |
| ⊘  | • Do not write on furniture without a padded barrier to protect the surface. |
| ✓  | • To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings. |
| ⊘  | • Stains may be removed with mild soap solution and damp cloth. |
| ✓  | • Keep away from sources of ignition. |
| ✓  | • Dust and pick-up spills using a clean, non-colored, lint-free cloth. |





Please look in Dining Chair for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.

DINING CHAIR













Parts List

Label	Picture	Description	QTY
A		Right Armrest	1
B		Left Armrest	1
C		Seat Board	1
D		Backrest	1
E		Back Cushion	1
F		Seat Cushion	1

Hardware			
Label	Picture	Description	QTY
①		Bolt (M6×18mm)	5
②		Bolt (M6×35mm)	5
③		Washer M6	9
④		Allen Wrench S4	1


Assembly Preparation

Before Beginning Assembly:						
	A	B	C	D	E	F
	 X 5		 X 5		 X 9	
	①		②		③	
						
					④	

-  • Read instructions, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assemble on flooring or carpet-
-  • Assemble on a clean non-marring surface (packing foam)-
-  • Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to 10 minutes to assemble. To give you an overview of the various parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Unpack and place all parts on a clean, soft surface.

Step 2






Place the Right Armrest(A) and Seat Board(C) on a clean ,non-marring surface. Attach Right Armrest(A) to Seat Board(C) using Bolts(②),and Washer(③) with Allen Wrench(④).

Step 3



Attach Left Armrest(B) to Seat Board(C) using Bolts(②),and Washer(③) with Allen Wrench(④).

<p>Step 4</p>	
<p>Attach Backrest (D) to Right Armrest (A) and Left Armrest(B) and Seat Board(C) using Bolts(1),and Washer(3) with Allen Wrench(4).</p>	
<p>Step 5</p>	
<p>Put Back Cushion (E) and Seat Cushion (F) fix the cushion to the chair using belt of the cushion</p>	
<p>Step 6</p>	
<p>Position the Chair on a level surface and test for stability. If the Chair is not Stable,fully tighten the Bolits. Your Chair is ready for use. This Chair can only be used on a flat, level surface.</p>	