# **Assembly Instructions**

Caution: You must read this before you proceed

## Care & Maintenance



• Not for commercial use. For residential use only.



• Do not put hot items directly on furniture surface.



• Do not clean furniture with harsh cleansers or polish.



• To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



• Do not write on furniture without a padded barrier to protect the surface.



 To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine.
 Whenever possible cover the product and /or place under patio or awnings.




• Stains may be removed with mild soap solution and damp cloth.



• Dust and pick-up spills using a clean, non-colored, lint- free cloth.

### Please look in the Leg Panel for hardware packs

# CHAIR




Parts List:				
Label	Picture	Description	QTY	
A		Upper Back Slat	2	
В		Middle Back Slat	1	
С		Lower Back Slat	1	
D		Seat Panel	1	
E		Right Leg Panel	1	
F		Left Leg Panel	1	
G		Back Cushion	1	
н		Seat Cushion	1	


Hardware:					
Label	Picture	Description	QTY		
1)		Screw (M6*90mm)	9		
2		Allen Wrench	2		
Assembly Preparation:					
Before Beginning Assembly:  (1) X9 (2) X2					
Ax2 B C					
Read instructions, cover to cover-  Have 2 adults on hand for assembly-  Do not assemble on flooring or carpet-  Assemble on a clean non-marring surface (packing foam)-  Save all packaging until finished-					

# Assembly Steps: Upper Back Slat (A) Left Leg Panel (F) Back Cushion (G) Seat Panel (D) FRONT FACING

This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.




Unpack and place all parts on a clean, non-marring surface.



With the help of your adult partner, put the tenon of Upper Back Slat (A), Middle Back Slat (B) and Seat Panel (D) into the mortise of the Left Leg Panel (F) and then secure by using Screw (1) and Allen Wrench (2) as shown above.


Do not fully tighten the Screws.






With the help of your adult partner, turn left side down the assembled part in Step 2 on a clean, non-marring surface.

Put the tenon of the remaining Upper Back Slat (A) and the Lower Back Slat (C) to the mortise of the Seat Panel (D) of the assembled part in Step 2 as shown above.



With the help of your adult partner, attach the Right Leg Panel (E) to the assembled part of Step 3 and then secure by using Screws (1) and Allen Wrench (2) as shown above. **Do not fully tighten the Screws.** 



Inspect it and make sure all parts are adequately connected.

Turn the Chair right side up.

Gently and gracefully, sit onto the Chair.

This will help to align all the parts at all joint areas.

Then get off the Chair and in a sequential manner, gradually tighten all Screws at all joints until evenly connected.

If there are still wobbles, loosen the Screws and execute this same process.

Place the Seat Cushion (H) by affix the Magic Tape Straps on the Seat Panel (D) and then place the Back Cushion (G) onto the Seat Cushion (H) as shown above.

# WARNING!! IF CHAIR IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Your Chair is ready for use.

This Chair can only be used on a flat, level surface.