


## **ASSEMBLY INSTRUCTIONS**







This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.






Take out Back Pillow (E) from Arms (A & B).







Attach Rear Leg (L) and Rear Middle Leg (M) to Seat (G) using Bolt (P) and Flat Washer (T) with L-Allen Key (O).




Attach Front Leg (K) and Front Middle Leg (N) to Seat (G) using Bolt (P) and Flat Washer (T) with L-Allen Key (O).




Attach Front & Rear Leg (K & L) to Arms (A & B) using Bolt (P) and Flat Washer (T) with L-Allen Key (O).




Insert Back (C) into Arms (A & B).





Paste the cloth cover of Back (C) to Rear Leg (L) and Rear Middle Leg (M).






Assemble Drawer (I) using Drawer Connector (S & V), then insert Bracket (U) into the middle of Drawer (I).






Attach Drawer (I) and Bracket (U) to Drawer Front (J) using Bolt (R) with L-Allen Key (O). Then, secure Bolt (Q) and Flat Washer (W) to Drawer Front (J) with L-Allen Key (O).



Move the assembled drawers under the Loveseat. The pin on the Drawer Front (J) can be locked into the slot on the Loveseat.



## **Cleaning & Care**

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.