


Notice:

- 1. Follow the installation instructions. Please confirm all accessories are preset before installation.
- 2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
- 3. If you encounter any problems during installation, please contact our customer service.
- 4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2



Put a carpet on the floor before unpacking




Estimate installation time: 30minutes


PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
A		X1	F		X2
B		X1	G		X4
C		X1	H	0	X2
D		X1			X1
E		X1	J	99	X4

HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	Ø8*30mm	X12+1	9		X8
2		X12+1	10	@1/4"*1"-1/4"	X2
3		X12+1	1		X2
4		X4	12		X2
5		X8	13	Ø4*25mm	X4
6		X4	14	Ø3*15mm	X26+2
7		X4	15		X1
8	Ø3*12mm	X48+4	16		X2






















































(5) 16PCS



10







Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm

Up-Down Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm



Common Door Panel Issues:

