

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in chair seat for hardware packs and legs.





ACCENT CHAIR



Parts List

Label	Picture	Description	QTY
A	A line drawing of the chair base, showing the seat and backrest without the legs.	Chair Base	1
B	A line drawing of a single front wooden leg, which is straight and tapered.	Front Wooden Leg	2
C	A line drawing of a single back wooden leg, which is curved and tapered.	Back Wooden Leg	1

Hardware List


Label	Picture	Description	QTY
①		Bolt(M6*40mm)	10
②		Washer(8*22mm)	10
③		Spring Washer	10
④		Allen Wrench	1

Assembly Preparation

Before
Beginning
Assembly:



A



B



C

①  X10

②  X10

③  X10

④  X1



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Take out the Wooden Legs(B&C) and Hardware Pack from the Leg Pouch.

Step 2




Put down the non-woven fabric.

Then place the Front Wooden Leg(B) at the front of the Chair Base(A) and align them with the installation position.

Attach the Front Wooden Leg(B) to the Chair Base(A) using Bolts(①) ,Washers(②) and Spring Washers(③) with the Allen Wrench(④).

Step 3




Stick non-woven fabric on.

Then place the Back Wooden Leg(C) at the back of the Chair Base(A) and align them with the installation position.

Attach the Back Wooden Leg(C) to the Chair Base(A) using Bolts(①) ,Washers(②) and Spring Washers(③) with the Allen Wrench(④).

Step 4



Position the Chair on a level surface and test for stability.

If the Chair is not Stable identify the Leg and Add/Remove a Gasket as needed.

Your Chair is ready for use.

This Chair can only be used on a flat, level surface.