








ASSEMBLY INSTRUCTIONS


NAILHEAD SWIVEL ACCENT CHAIR

A Chair	B Swivel Chair Base	C Bolt Ø1/4" x 1"	D Flat Washer Ø1/4" x 16mm
			
1PC	1PC	4PCS	4PCS
E Spring Washer Ø1/4"	F Allen Wrench 4mm		
			
4PCS	1PC		




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1 Take out the Swivel Chair Base (B) and Hardware Pack from the inner carton.



- 2 Turn the Chair (A) upside down and place it on a protective carpet. Attach the Swivel Chair Base (B) to the Chair (A) using Bolt (C), Spring Washer (E) and Flat Washer (D) with the Allen Wrench (F).



-
- 3** While seated in the chair, enjoy the 360-degree swivel feature.



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.