


Assembly Instruction




Dining chairs








ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Parts List


Number	Name	Part	Qty
1	Seat		x1PC
2	Back Leg		x2PCS
3	Front Leg		x2PCS

Number	Hardware	Part	Qty
A	M6*20mm		x12+1EXT
B	Washer		x12+1EXT
C	Foot levelers		x4+1PC
D	Allen Wrench		x1PC




②

Ensure that each
screw is tightened



Rotate it to ensure the chair
is flat on the floor !



Additional Note About Safety: Bolts may loosen during normal everyday use. They should be periodically inspected and tightened to prevent damage or injury. Always check to be sure that all hardware is kept tightened. Thank you for your purchase.