

Assembly Manual Dining Chair BC8001



Please read this manual carefully before any operation and keep it properly for future use.


Assembly-note:




Put a protective mat on the ground and handle the product with care.




 \bigcirc Two people are preferred.



3 Contact us if you have any confusions




Exploded diagram:



NO.	Name	PCS
1	Backrest with leg	1
2	Seat cushion	1
3	Side rail - LSF/RSF	2
4	Stretcher	2
5	Front leg frame	1

Accessory list:


screwdriver




Note:The number after "+" sign indicates the extra piece(s).


Tighted the screws in 50% after all connection in right position.

Tighted the screws in 50% (5) Tighted the screws in 50% after all connection in right position.




Tighted all the screws in 100% after all connection in right position (include step1 and step 2).





Tighted the screws in 100% after all connection in right position. Legs levels can be modified by adjustable foot nails under bottom of the front legs

5







Warning

- Please keep the product away from children while assembling.
- Do not let children play or jump on the product.
- Do not stand on the item or use as a step ladder.
- Prior to use, please check to see if there's any loosening screw or part.
- Make sure that each screw and part is correctly installed and securely fastened.

Care and Maintenance

- Use a soft clean cloth that will not scratch the surface when dusting
- There's no need to use furniture polish. If you need, test it first
 in an inconspicuous area.
- Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately.
- Gently blot the spill with a soft clean cloth to avoid rubbing.

Further advice about the furniture care

- It is best to keep your furniture in a climate-controlled environment.
- Extreme temperatures and humidity changes can cause fading.warping, shrinking and spitting of wood.
- We recommend to keep furniture from sunlight exposure to avoid possible surface damage.
- Proper maintenance and cleaning at home will extend the life of your purchase.
- Following these important and helpful tips will help retain your furniture's performance even when it ages.
 Periodically(every 90 days) make sure the screws are fully tightened.