






Assembly Instruction for

COFFEE TABLE


RS2401-01 RS2401-02

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please Put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST				HARDWARE LIST			
No.		CODE.	QTY	NO.	HARDWARE DESC	CODE.	QTY
A	GLASS PANEL		1	1	 WOOD SCREW	COFFEE TABLE	12
B	TABLE LEG		2	2	 ECCENTRIC WHEEL		12
C	TABLE LEG		2	3	 WOODEN TIP		8
D	SUPPORT PLATE		1	4	 BEAUTY PATCH		12
				5	 SUCTION CUPS		4


NOTES : Do not fully tighten any bolts until last step.

TOOLS REQUIRED (NOT PROVIDED)	
	Phillips Screw Driver


STEP : 1




STEP : 2



STEP : 3




STEP : 4





Assembly Instruction for
COFFEE TABLE
RS2401-01 RS2401-02

STEP : 5



STEP : 6



Install the panel and remove the red label

COMPLETED

