






ITEM NAME/NOM D'ITEM: STENGER DINING CHAIR
ITEM#/NO. ITEM: 110519/110520

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)	(6)
 x1	 FL x1	 FR x1	A.  M6 x 30MM x6 B.  M6 x 45MM x4 C.  M6 x 10 x 13MM x4 D.  M13.5 x 7MM x4 E.  Ø12MM x6 F.  Ø13MM x6 G.  4MM x1
(4)	(5)		
 341 x Ø28 mm x1	 313 x Ø28 mm x1		

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

Do not FULLY TIGHTEN the screws or nuts for any step until all are in place.



I

80% tighten




II

100% tighten



III.



For missing part or damaged parts, please call /

Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico:(866)798-6663

AI-V1-F008-250623