


ASSEMBLY INSTRUCTIONS

ARMLESS CHAIR WITH DOWN FEATHER CUSHION


ARMS

A Seat Frame



1pc

B Back Frame




1pc

C Arm (L)




1pc

D Arm (R)




1pc

E Seat Cushion




1pc

F Back Cushion




1pc

G Leg




8pcs

H Plastic Head Bolt
5/16" x 2-1/2"




3pcs

I Plastic Washer
φ 2"





8pcs





This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.



1 Attach the Seat Frame (A) to the Back Frame (B), tightening them by turning the Plastic Head Bolt (H).





2 Attach the Leg (G) with Plastic Washer (I) to the Seat & Back Frame (A & B) and the Arm (L/R) (C & D).



3 Attach the Arm (L/R) (C & D) to the Armless Chair (A & B), tightening them by turning the Plastic Head Bolt (H).



4 Place the Seat Cushion (E) and Back Cushion (F) onto the Chair.





Cleaning & Care



Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

More Options



1 Option: 1





2 Option: 2





3 Option: 3




4 Option: 4



5 Option: 5




COMPLETE




ASSEMBLY INSTRUCTIONS

OTTOMAN WITH DOWN FEATHER CUSHION



A Ottoman



B Leg
(Inside the Ottoman)




C Plastic Washer
(Inside the Ottoman)
φ 2"




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

-
- 1** Unzip the bottom of the Ottoman (A) to take out the Leg (B) and Plastic Washer (C).



-
- 2** Attach the Leg (B) with Plastic Washer (C) to the bottom of the Ottoman (A).



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.