Assembly Instructions

CAUTION: You must read these Assembly Instructions before you proceed.




Never adjust chaise lounge or recliner backrest while seated.

Always make sure the backrest is flat before moving the chaise lounge.

Keep all limbs clear from under the backrest when it is in a raised position.

Serious finger, hand, or other bodily injuries may result from adjusting the chaise lounge backrest position while seated.



The examples pictured above are non exhaustive and are for your reference only


Care & Maintenance



- Not for commercial use. For residential use only.
- Ø 💆 .
 - Do not put hot items directly on furniture surface.
- 0
- Do not clean furniture with harsh cleansers or polish.
- √:Ö:
- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.
- 0 1/
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- **√** ⇔
- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine.

 Whenever possible cover the product and /or place under patio or awnings.
- 0
- Stains may be removed with mild soap solution and damp cloth.
- **√**
- Dust and pick-up spills using a clean, non-colored, lint- free cloth.

1




Parts List:				
Label	Picture	Description	QTY	
A		Back Leg Panel	1	
В		Front Leg Panel	1	
С		Seat Panel	1	
D		Support Leg	1	
E	0	Wheel	2	
F		Cushion	1	

Hardware:				
No	Picture	Description	QTY	
1		Screw (M6*20mm)	3	
2		Bolt (M6*80mm)	5	
3		Wheel Hub (M10*70mm)	2	
4		Cross Nut (M6*13mm)	5	
(5)		Flat Washer (M10*3mm)	2	
6		Allen Wrench	2	

Assembly Preparation:

Before Beginning Assembly:





• Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

4


Assembly Steps:



This Chaise Lounge has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chaise Lounger parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.




Unpack and place all parts on a clean, non-marring surface.



With the help of your adult partner, attach the Wheel (E) to the Back Leg Panel (A) by using Wheel Hub (3), Flat Washer (5) and Allen Wrench (6) as shown above.

Repeat the same process with the remaining Wheel (E).

Do not fully tighten the Wheel Hubs.




With the help of your adult partner, place the Seat Panel (C) facing down as shown above.

Step 3.1, attach the assembled part in Step 2 to the Seat Panel (C) and then secure by using Bolts (2), Cross Nuts (4) and Allen Wrench (6) as shown in the picture above.

Note: Affix the Bolt (2) into the Cross Nut (4) inside the Seat Panel (C) then remove Bolt (2) from the Cross Nut (4). Step 3.2, attach the Support Leg (D) to the Seat Panel (C) and then secure by using Screws (1) and Allen Wrench (6) as shown above.

Step 3.3, attach the Front Leg Panel (B) to the Seat Panel (C) and then secure by using Bolts (2), Cross Nuts (4) and Allen Wrench (6) as shown in the picture above.

Note: Affix the Bolt (2) into the Cross Nut (4) inside the Seat Panel (C) then remove Bolt (2) from the Cross Nut (4). Do not fully tighten the Screws and Bolts.



Inspect it and make sure all parts are adequately connected.

Turn the Chaise Lounge right side up.

Gently and gracefully, sit onto the Chaise Lounge.

This will help to align all the parts at all joint areas.

Then get off the Chaise Lounge and in a sequential manner, gradually tighten all Bolts, Screws at all joints until evenly connected.

If there are still wobbles, loosen the Bolts, Screws and execute this same process.

Adjust Pre-installed Leveler height for balance as shown above.

Place the Cushion (F) by affix the Magic Tape Straps on the Seat Panel (C) as shown above.

WARNING!! IF CHAISE LOUNGE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT. Your Chaise Lounge is ready for use.

This Chaise Lounge can only be used on a flat, level surface.

Note: Align the Backrest of Chaise Lounge in position you want.