





ASSEMBLY INSTRUCTION

















Notice: Install relevant screws, don't tighten completely at beginning Alignment & Tighten fully when you complete the seat base section.




Notice: Install relevant screws, don't tighten completely at beginning Alignment & Tighten fully when you complete the seat base section.




Notice: Install relevant screws, don't tighten completely at beginning Alignment & Tighten fully when you complete the seat base section.




Notice: Install relevant screws, don't tighten completely at beginning Alignment & Tighten fully when you complete the seat base section.



Notice: Install relevant screws, don't tighten completely at beginning Alignment & Tighten fully when you complete the seat base section.



Notice: Install relevant screws, don't tighten completely at beginning Alignment & Tighten fully when you complete the seat base section.



Notice: Install relevant screws, don't tighten completely at beginning Alignment & Tighten fully when you complete the seat base section.