
ASSEMBLY INSTRUCTIONS BATH VANITY-CABINET

SKU - N817P286250



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED



*Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!

* Please assemble on a clean soft surface to avoid damage.










(Not included)



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


Before Installation


Important- Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions











Part Lists N817P286250						
15	Door Cabinet (L) - 1pc	Door Cabinet (R) - 1pc				
17	Sink - 1pc					


Hardware Lists N817P286250						
A		В		C		
	Ø8*30mm		Ø6*32mm	Ø14.5*9.5mm		
	Wood dowel (16pcs)+1Pc	Three in on bolt (4pcs)+1Pc		Three in one lock (4pcs)+1Pc		
D	One One One	E	Other Other Other Other Other Other	Ø13xM6*30mm		
	Damping hinge (4 sets)	Small Damping hinge (2 sets)		Hex-Head bolt (12pcs)+1Pc		
G		Н				
	K4mm			Ø8xM4*22mm		
	Allen key (1pc)+1Pc		Knob (4pcs)	Handle screw (4pcs)		
J	45*12*1mm	K				
	45*17*14mm		Ø8xØ3.5*15mm	Ø8xØ3.5*15mm		
Plastic Door Magnet (2 sets)		Round head screw (8pcs)+1Pc		Flat head screw (8pcs)+1Pc		
M	Ø10*10mm	N	<i>€ page to the transposition of the transpositio</i>	O Ø8xØ4*25mm		
F	Plastic Canopy (4pcs)+1Pc	Rour	nd head screw (4pcs)+1Pc	Flat head screw (2pcs)+1Pc		
Р	0	Q		R		
	Spring Washer (4 pcs)+1Pc	F	lat washer (4 pcs)+1Pc	Shelf pin(4pcs)		
S		Τ		U		
Left elbow hinge (1pc)		F	Right elbow hinge (1pc)	Anti fall Hardware (2 sets)		
V						
	Ø8xØ3*12mm					
F	lat head screw (8pcs)+1Pc					
		I	7	1		



























HINGE ADJUSTMENTS



1 Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from
the side of the cabinet

anticlockwise to move the door closer to the
side of the cabinet

(2) (4) Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up **anticlockwise** to move the door down

(3) Forward and back adjustment

